

Model **XS400D**
Year **1977**
Disp **400**
Desc **XS400**
Type **Street**
Code **2A2**

Part No.	Item	Assembly	Quantity
1L9-81600-50-00	Ac Generator Assembly	Ac Generator	1
1L9-81650-50-00	Rotor Assembly	Ac Generator	1
1L9-81610-50-00	Stator Assembly	Ac Generator	1
1L9-81660-50-00	Field Coil Assembly	Ac Generator	1
91316-06015-00	Bolt, Hexagon Socket Head	Ac Generator	3
91316-06030-00	Bolt, Hexagon Socket Head	Ac Generator	3
90101-10105-00	Bolt, Hexagon (341-18652-00)	Ac Generator	1
92903-10100-00	Washer, Spring Use With Crank (l.h.) 214-11412-00-00	Ac Generator	1
90201-10508-00	Washer, Plate (10.1-24-5) (341-81663-01)	Ac Generator	1
1L9-27211-00-33	Pedal, Brake Yamaha Black	Brake Pedal - Rear Master Cylinder	1
90109-06468-00	Bolt, Hexagon	Brake Pedal - Rear Master Cylinder	1
92903-06100-00	Washer, Spring Use With 214-15121-01-00 To 291-15121-00-00 Crankcase	Brake Pedal - Rear Master Cylinder	1
90508-40344-00	Spring, Torsion	Brake Pedal - Rear Master Cylinder	1
1U4-27212-00-00	Shaft, Brake Pedal	Brake Pedal - Rear Master Cylinder	1
1J3-27222-00-00	Joint	Brake Pedal - Rear Master Cylinder	1
90240-08013-00	Pin, With Hole (307-18118-00)	Brake Pedal - Rear Master Cylinder	1
90201-08083-00	Washer, Pedal Link (8.2-13-0.6) (156-27226-00)	Brake Pedal - Rear Master Cylinder	1
91401-16015-00	Pin, Cotter Alternate Parts	Brake Pedal - Rear Master Cylinder	1
1J3-27231-00-00	Rod, Brake	Brake Pedal - Rear Master Cylinder	1
95301-08700-00	Nut (92801-08300) For Folding Footrest	Brake Pedal - Rear Master Cylinder	1
90153-06008-00	Screw, Cross Recess (341-27217-00)	Brake Pedal - Rear Master Cylinder	1
90170-06184-00	Nut (90170-06273)	Brake Pedal - Rear Master Cylinder	1
1U4-25850-50-00	Master Cylinder Assembly, Rear	Brake Pedal - Rear Master Cylinder	1
1U4-W0042-50-00	Cylinder Kit, Master	Brake Pedal - Rear Master Cylinder	1
1J3-25852-51-00	Cap, Reservoir Rear	Brake Pedal - Rear Master Cylinder	1
1J3-25854-51-00	Diaphragm, Reservoir	Brake Pedal - Rear Master Cylinder	1
1J3-25855-51-00	Bushing, Diaphragm	Brake Pedal - Rear Master Cylinder	1
90153-05014-00	Screw, Cross Recess	Brake Pedal - Rear Master Cylinder	3
1J3-25862-50-00	Boot, Master Cylinder	Brake Pedal - Rear Master Cylinder	1
97321-08016-00	Bolt, Hexagon (97321-08015)	Brake Pedal - Rear Master Cylinder	2

92903-08100-00	Washer, Spring (92902-08100) (optional Parts)	Brake Pedal - Rear Master Cylinder	2
1U4-25872-50-00	Hose, Rear Brake	Brake Pedal - Rear Master Cylinder	1
90401-10034-00	Bolt, Union (90201-10118)	Brake Pedal - Rear Master Cylinder	2
90201-10118-00	Washer, Oil Bolt (10.2-14-1.0) (306-25878-00)	Brake Pedal - Rear Master Cylinder	4
90461-08031-00	Clamp 1	Brake Pedal - Rear Master Cylinder	3
92906-06100-00	Washer, Spring California Model Only	Brake Pedal - Rear Master Cylinder	3
97306-06012-00	Bolt	Brake Pedal - Rear Master Cylinder	3
1L9-W0031-00-00	Front Bumper Kit	Bumper	1
1L9-24872-00-00	Stay, Bumper Left	Bumper	1
1L9-24873-00-00	Stay, Bumper Right	Bumper	1
95801-08070-00	Bolt, Flange	Bumper	1
92903-08100-00	Washer, Spring (92902-08100) (optional Parts)	Bumper	1
95301-08600-00	Nut (98801-08100) Optional Parts	Bumper	1
95801-10025-00	Bolt, Flange	Bumper	2
92903-10100-00	Washer, Spring Use With Crank (l.h.) 214-11412-00-00	Bumper	2
92903-10200-00	Washer, Spring (92901-10200)	Bumper	2
1L9-W0032-00-00	Rear Bumper Kit	Bumper	1
90201-10142-00	Washer (10.5-27-4.5) (341-22243-00)	Bumper	2
1M0-12171-00-00	Camshaft 1	Camshaft - Chain Tensioner	1
1L9-12176-00-00	Sprocket, Cam Chain (34t)	Camshaft - Chain Tensioner	1
90105-07087-00	Bolt, Washer Based Head Hexagon P07-11l	Camshaft - Chain Tensioner	2
94500-02092-00	Chain, Camshaft (bf05m 92l) (usa)	Camshaft - Chain Tensioner	1
1L9-12231-00-00	Guide, Stopper 1	Camshaft - Chain Tensioner	1
1L9-12241-02-00	Guide, Stopper 2	Camshaft - Chain Tensioner	1
1L9-12210-01-00	Tensioner Assembly	Camshaft - Chain Tensioner	1
95801-06016-00	Bolt, Flange	Camshaft - Chain Tensioner	2
93603-07073-00	Locating Pin, Governor M5-016	Camshaft - Chain Tensioner	1
93102-23152-00	Oil Seal (sd-23-35-5)	Camshaft - Chain Tensioner	1
2A2-14900-60-00	Carburetor Assembly L/r Set	Carburetor	1
2A2-14901-60-00	Carburetor Assembly, Left	Carburetor	1
2A2-14902-60-00	Carburetor Assembly, Right	Carburetor	1
2A2-14941-04-00	Nozzle, Main	Carburetor	2
2A2-14116-01-00	Needle	Carburetor	2
2A2-14940-00-00	Diaphragm Assembly	Carburetor	2
2F3-14940-00-00	Diaphragm Assembly	Carburetor	2
2A2-14933-00-00	Spring, Diaphragm	Carburetor	2
2A2-14958-00-00	Cover, Diaphragm Exclusive For Carburetor 2, 3	Carburetor	2
98503-05015-00	Screw, Pan Head Oil Pump Assembly Refer To M8-0150	Carburetor	8
620-14231-79-00	Jet, Main (#142.5)	Carburetor	2
137-14153-00-00	Washer, Main Jet (usa)	Carburetor	2
256-14142-42-00	Jet, Pilot (no. 42.5) (256-14942-42) 003629~	Carburetor	2
2F3-14991-00-00	Screw, Plug (2a2-14991-00)	Carburetor	2

1J7-14994-00-00	Net, Filter (usa)	Carburetor	2
239-14195-00-00	Washer, Valve Seat M4-108	Carburetor	2
1J7-14190-20-00	Valve Seat Assembly (#2.0)	Carburetor	2
537-14186-00-00	Pin, Float (usa)	Carburetor	2
2A2-14985-00-00	Float	Carburetor	2
2A2-14984-01-00	Gasket, Float Chamber (2a2-14984-00)	Carburetor	2
2A2-14981-06-00	Body, Float Chamber For Middle	Carburetor	2
1A8-14991-00-00	Screw, Plug Se114241~	Carburetor	2
1L9-14952-00-00	Washer, Drain Bolt	Carburetor	4
98503-05015-00	Screw, Pan Head Oil Pump Assembly Refer To M8-0150	Carburetor	8
92903-05100-00	Washer, Spring (92901-05100) Alternate Parts	Carburetor	8
2A2-14923-00-00	Screw, Pilot	Carburetor	2
8A7-14969-00-00	Cap, Pilot Screw	Carburetor	2
256-14934-01-00	Spring, Throttle Stop Se114241~	Carburetor	4
256-14922-01-00	Screw, Throttle Stop Se114241~	Carburetor	1
584-14992-00-00	Rod, Push Se114241~	Carburetor	1
584-14934-00-00	Spring, Adjusting Se114241~	Carburetor	1
256-14937-00-00	Clip Pn343	Carburetor	1
2A2-14964-00-00	Lever, Throttle Left	Carburetor	1
1L9-14918-00-00	Ring	Carburetor	1
2A2-14931-00-00	Spring, Throttle Left	Carburetor	1
95301-12600-00	Nut, Hexagon (98801-12200)	Carburetor	2
256-14953-00-00	Screw, Pan Head	Carburetor	2
306-14970-00-00	Collar, Spring Exclusive For Carburetor 3, 4	Carburetor	2
2A2-14963-00-00	Lever, Throttle Right	Carburetor	1
2A2-14918-00-00	Ring	Carburetor	1
2A2-14997-00-00	Seal (usa)	Carburetor	2
2A2-14932-00-00	Spring, Throttle Lever Middle	Carburetor	1
2A2-14922-00-00	Adjuster Assembly	Carburetor	1
1J7-14998-00-00	Bushing, Adjuster	Carburetor	1
2A2-14995-00-00	Bracket	Carburetor	1
98501-04008-00	Screw, Pan Head (98503-04008) Used On All 211-23100-Xx, Front Fork	Carburetor	2
92901-04100-00	Washer, Spring Used On 168-81200-22	Carburetor	2
1L9-14988-00-00	Pipe, Starter Connecting	Carburetor	1
1L9-14166-00-00	Bolt, Banjo	Carburetor	1
93501-08001-00	Ball (1/8 Inch)	Carburetor	2
583-14589-00-00	Spring	Carburetor	2
2A2-14171-00-00	Plunger, Starter Assembly	Carburetor	2
256-14135-00-00	Spring, Plunger Se114241~	Carburetor	2
2A2-14174-00-00	Cap, Plunger	Carburetor	2
2A2-14173-00-00	Cover, Plunger Cap	Carburetor	2
2A2-14172-34-00	Jet, Air Pilot (#170)	Carburetor	2

2F0-14919-00-00	Clip Se114241~	Carburetor	2
2F3-14946-00-00	Plate, Needle Fitting (2f0-14946-00)	Carburetor	2
2F0-14918-00-00	Ring Se114241~	Carburetor	2
256-14919-00-00	Clip Se114241~	Carburetor	2
2F3-14952-00-00	Washer, Needle	Carburetor	2
2F0-14589-00-00	Spring Se114241~	Carburetor	2
2A2-14977-00-00	Shaft, Starter Lever	Carburetor	1
2A2-14905-00-00	Lever, Starter	Carburetor	2
2F3-14991-00-00	Screw, Plug (2a2-14991-00)	Carburetor	2
2A2-14926-00-00	Plate, Upper	Carburetor	1
1L9-14987-00-00	Hose	Carburetor	1
1L9-14146-00-00	Plate, Lower	Carburetor	1
92503-06015-00	Screw, Pan Head (92501-06016-00) 008171-	Carburetor	4
1L9-16301-00-00	Clutch Assembly	Clutch	1
1L9-16150-01-00	Primary Driven Gear Comp. (78t)	Clutch	1
90201-25291-00	Washer, Plate (25.2-39-1.0) (371-11558-00)	Clutch	1
1L9-16371-00-00	Boss, Clutch	Clutch	1
383-16321-00-00	Plate, Friction	Clutch	7
168-16325-00-00	Plate, Clutch 2 (t1.6) (usa)	Clutch	6
1L9-16351-00-00	Plate, Pressure 1	Clutch	0
90501-26148-00	Spring, Clutch (256-16333-00) 001080~	Clutch	4
90159-06010-00	Screw, Cross Recess Hexagon	Clutch	4
1L9-16356-00-00	Rod, Push 1	Clutch	1
93410-24042-00	Circlip (s-24)	Clutch	1
168-17428-01-03	Shim, Drive Axle (25-34-0-3) Canada Only Ur	Clutch	0
168-17428-01-05	Shim, Drive Axle (25-36-1.5) (168-17428-00) Used On (168-17421-00), Transmission	Clutch	1
93505-16006-00	Ball, Steel (5/16 Inch)	Clutch	1
371-16357-02-00	Rod, Push 2	Clutch	1
93102-09151-00	Oil Seal (sd-8.8-22-7.5)	Clutch	1
1L9-16340-00-00	Push Lever Assembly	Clutch	1
214-16347-01-00	Seal, Dust 001125~	Clutch	1
371-16396-00-00	Housing, Push Screw (256-16396-01)	Clutch	1
98503-05012-00	Screw, Pan Head 010651 -Xs750d M7-022 100101 -Xs750-2d	Clutch	2
90113-08021-00	Screw, Adjusting (256-16343-01) 001125~	Clutch	1
90179-08179-00	Nut, Adjusting (214-16344-00)	Clutch	1
214-16389-00-00	Joint, Pin M5-040	Clutch	1
90240-06005-00	Pin, With Hole (214-16379-00)	Clutch	1
91401-10010-00	Pin, Cotter (91402-10006)	Clutch	1
90506-10023-00	Spring, Return (168-16345-00) 001125~	Clutch	1
1L9-81620-50-00	Breaker Plate Assembly	Contact Breaker - Governor	1
1L9-81621-51-00	Contact Breaker Assembly, Left (119-81621-50)	Contact Breaker - Governor	1
1L9-81622-51-00	Contact Breaker Assembly, Right (119-81622-50)	Contact Breaker - Governor	1

1L9-81631-50-00	Lubricator	Contact Breaker - Governor	1
1L9-81634-50-00	Lead Wire Assembly	Contact Breaker - Governor	1
110-81345-21-00	Screw, Cylinder Head (4-6) (110-81345-20)	Contact Breaker - Governor	4
92901-04100-00	Washer, Spring Used On 168-81200-22	Contact Breaker - Governor	4
92901-04200-00	Washer, Plate (1I9-81655-50)	Contact Breaker - Governor	4
1L9-81653-50-00	Governor Assembly	Contact Breaker - Governor	1
92503-06015-00	Screw, Pan Head (92501-06016-00) 008171-	Contact Breaker - Governor	2
92903-06200-00	Washer, Push Lever (6.2-15-1) (122-16359-00)	Contact Breaker - Governor	4
97301-06020-00	Bolt (91201-06020)	Contact Breaker - Governor	1
90201-06060-00	Washer, Plain (6-18-1.6) (132-18338-00)	Contact Breaker - Governor	1
2A2-15100-00-00	Crankcase Assembly	Crankcase	1
1L9-15100-01-00	Crankcase Assembly	Crankcase	1
90105-08084-00	Bolt, Washer Based Head Hexagon M8-150I	Crankcase	1
91830-21014-00	Pin, Dowel (6.4-10-14) (91810-02014)	Crankcase	2
1L9-15138-00-00	Nozzle	Crankcase	1
90105-06073-00	Bolt, Washer Based Head Hexagon M6-45I	Crankcase	5
90105-06074-00	Bolt, Washer Based Head Hexagon M6-50I	Crankcase	6
90105-06076-00	Bolt, Washer Based Head Hexagon M6-80I	Crankcase	1
90105-06077-00	Bolt, Washer Based Head Hexagon M6-105I	Crankcase	2
90105-08081-00	Bolt, Washer Based Head Hexagon M8-80I	Crankcase	1
90105-08082-00	Bolt, Washer Based Head Hexagon M8-110I	Crankcase	2
90105-08084-00	Bolt, Washer Based Head Hexagon M8-150I	Crankcase	3
90465-10092-00	Clamp	Crankcase	1
90465-10110-00	Clamp	Crankcase	1
90105-06069-00	Bolt, Washer Based Head Hexagon	Crankcase	1
1L9-15412-00-00	Plate, Oil Guide	Crankcase	1
98501-05010-00	Screw, Pan Head (98503-05008) Used On 235-15411-00	Crankcase	2
90340-14034-00	Plug, Straight Screw (431-15351-00)	Crankcase	1
90430-14042-00	Gasket (14.1-21-1.0) (341-15396-00)	Crankcase	1
1L9-15123-00-00	Plate, Baffle 1	Crankcase	1
1L9-15124-00-00	Plate, Baffle 2	Crankcase	1
1L9-15122-00-00	Bar, Baffle Plate Fixed	Crankcase	1
1L9-11108-00-00	Breather Cover Assembly	Crankcase	1
1L9-11169-00-00	Gasket, Breather Cover	Crankcase	1
90105-06071-00	Bolt, Washer Based Head Hexagon	Crankcase	4
90465-08111-00	Clamp	Crankcase	1
1L9-11166-00-00	Pipe, Breather 1	Crankcase	1
90467-14015-00	Clip (90467-14056)	Crankcase	2
90340-22047-00	Plug, Straight Screw	Crankcase	1
90430-22144-00	Gasket Use Set For Interchange	Crankcase	1
1L9-15411-00-00	Cover, Crankcase Left 1	Crankcase Cover	1
1L9-15461-00-00	Gasket, Crankcase Cover Left	Crankcase Cover	1

91316-06030-00	Bolt, Hexagon Socket Head	Crankcase Cover	5
91316-06040-00	Bolt, Hexagon Socket Head 1	Crankcase Cover	3
91830-21014-00	Pin, Dowel (6.4-10-14) (91810-02014)	Crankcase Cover	4
1L9-15415-01-00	Cover, Generator 1	Crankcase Cover	1
1L9-15455-01-00	Gasket, Carburetor Cover 1	Crankcase Cover	1
91316-05015-00	Bolt, Hexagon Socket Head	Crankcase Cover	4
1L9-15421-00-00	Cover, Crankcase Left 2	Crankcase Cover	1
91316-06065-00	Bolt, Hexagon Socket Head M6-65l	Crankcase Cover	4
91316-06040-00	Bolt, Hexagon Socket Head 1	Crankcase Cover	1
1L9-15441-00-00	Holder, Clutch Wire 1	Crankcase Cover	1
1L9-15417-00-00	Cover, Cap 1	Crankcase Cover	1
1L9-15431-01-00	Cover, Crankcase 3	Crankcase Cover	1
1L9-15451-00-00	Gasket, Crankcase Cover Right 1	Crankcase Cover	1
91830-21014-00	Pin, Dowel (6.4-10-14) (91810-02014)	Crankcase Cover	2
91316-06030-00	Bolt, Hexagon Socket Head	Crankcase Cover	3
91316-06040-00	Bolt, Hexagon Socket Head 1	Crankcase Cover	1
1L9-15362-00-00	Plug, Oil Level 1	Crankcase Cover	1
93210-27194-00	O-Ring (2.5-27.0)	Crankcase Cover	1
2A2-11411-00-00	Crankshaft	Crank - Piston	1
1L9-11650-00-00	Connecting Rod Assembly	Crank - Piston	2
371-11654-01-00	Bolt, Connecting Rod	Crank - Piston	4
90170-08129-00	Nut, Hexagon (371-11655-00)	Crank - Piston	4
1L9-11656-00-00	Plane Bearing, Connecting Rod Ur Blue	Crank - Piston	0
1L9-11656-10-00	Plane Bearing, Connecting Rod U. R. Black	Crank - Piston	0
1L9-11656-20-00	Plane Bearing, Connecting Rod U. R. Brown	Crank - Piston	0
1L9-11656-30-00	Plane Bearing, Connecting Rod U. R. Green	Crank - Piston	0
2A2-11631-00-Y0	Piston (size B Std) (2a2-11631-00-X0)	Crank - Piston	2
2A2-11635-00-00	Piston (69.25mm 1st O/s) Alternate Parts	Crank - Piston	2
2A2-11636-00-00	Piston (69.50mm 2nd O/s) Alternate Parts	Crank - Piston	2
2A2-11637-00-00	Piston (69.75mm 3rd O/s) Alternate Parts	Crank - Piston	2
2A2-11638-00-00	Piston (70.00mm 4th O/s) Alternate Parts	Crank - Piston	2
2A2-11610-00-00	Piston Ring Set (std)	Crank - Piston	2
2A2-11610-10-00	Piston Ring Set (1st O/s) Alternate Parts	Crank - Piston	2
2A2-11610-20-00	Piston Ring Set (2nd O/s) Alternate Parts	Crank - Piston	2
2A2-11610-30-00	Piston Ring Set (3rd O/s) Alternate Parts	Crank - Piston	2
2A2-11610-40-00	Piston Ring Set (4th O/s) Alternate Parts	Crank - Piston	2
2A2-11633-00-00	Pin, Piston	Crank - Piston	2
93450-17044-00	Circlip (usa)	Crank - Piston	4
1L9-11416-00-00	Plane Bearing, Crankshaft 1 Ur Blue	Crank - Piston	0
1L9-11416-10-00	Plane Bearing, Crankshaft 1 U. R. Black	Crank - Piston	0
1L9-11416-20-00	Plane Bearing, Crankshaft 1 U. R. Brown	Crank - Piston	0
1L9-11416-30-00	Plane Bearing, Crankshaft 1 U. R. Green	Crank - Piston	0

90280-05015-00	Key, Woodruff	Crank - Piston	1
1L9-16111-00-00	Gear, Primary Drive (24t)	Crank - Piston	1
90105-10085-00	Bolt, Washer Based Head Hexagon Pa10-25l	Crank - Piston	1
90280-04005-00	Key, Woodruff (341-11545-00) Alternate Parts	Crank - Piston	1
2A2-11101-00-00	Cylinder Head Assembly	Cylinder Head - Cylinder	1
1L9-11133-10-00	Guide, Valve Intake (1st O/s) Alternate Part	Cylinder Head - Cylinder	4
93440-12052-00	Circlip (120 Special)	Cylinder Head - Cylinder	4
91830-21014-00	Pin, Dowel (6.4-10-14) (91810-02014)	Cylinder Head - Cylinder	2
90105-08079-00	Bolt, Washer Based Head Hexagon M8-50l	Cylinder Head - Cylinder	1
91800-16016-00	Pin, Dowel (10.5-14-16) (91810-16016)	Cylinder Head - Cylinder	5
90430-14131-00	Gasket, Dowel Pin	Cylinder Head - Cylinder	1
2A2-11181-00-00	Gasket, Cylinder Head 1	Cylinder Head - Cylinder	1
2A2-11311-00-00	Cylinder	Cylinder Head - Cylinder	1
93210-74316-00	O-Ring, Cylinder Base	Cylinder Head - Cylinder	2
2A2-11351-00-00	Gasket, Cylinder Base	Cylinder Head - Cylinder	1
90387-16547-00	Collar (16.5-18-10)	Cylinder Head - Cylinder	1
93210-18322-00	Cylinder Stud O-Rings Replace When Performing Top End Repairs	Cylinder Head - Cylinder	1
1L9-11361-00-00	Bolt, Cylinder Holding 1	Cylinder Head - Cylinder	4
1L9-11362-00-00	Bolt, Cylinder Holding 2	Cylinder Head - Cylinder	4
90201-10128-00	Washer, Plate (10.5-20-2) (341-83909-00)	Cylinder Head - Cylinder	8
1L9-11171-00-00	Nut, Cylinder Holding	Cylinder Head - Cylinder	8
90105-06070-00	Bolt, Washer Based Head Hexagon M6-25l	Cylinder Head - Cylinder	2
90105-06073-00	Bolt, Washer Based Head Hexagon M6-45l	Cylinder Head - Cylinder	4
90105-06075-00	Bolt, Washer Based Head Hexagon M6-60l	Cylinder Head - Cylinder	2
90105-08078-00	Bolt, Washer Based Head Hexagon M8-40l	Cylinder Head - Cylinder	1
90105-08079-00	Bolt, Washer Based Head Hexagon M8-50l	Cylinder Head - Cylinder	4
90105-08080-00	Bolt, Washer Based Head Hexagon M8-60l	Cylinder Head - Cylinder	2
90201-06630-00	Washer, Plate	Cylinder Head - Cylinder	2
1L9-11186-00-00	Cover, Cylinder Head Side 2 (usa)	Cylinder Head - Cylinder	4
93210-32172-00	O-Ring (2.4-31.5) 102260~ Canada	Cylinder Head - Cylinder	4
1L9-11157-00-00	Cover, Breaker 1	Cylinder Head - Cylinder	1
1L9-11146-00-00	Gasket, Breaker Cover	Cylinder Head - Cylinder	1
98501-05035-00	Screw, Pan Head Iso	Cylinder Head - Cylinder	2
90116-08046-00	Bolt, Stud (823-13558-00)	Cylinder Head - Cylinder	4
94701-00117-00	Plug, Spark (ngk Bp-7es) U. R.	Cylinder Head - Cylinder	0
94701-00135-00	Plug, Spark (champion (n-7y) U. R.	Cylinder Head - Cylinder	2
1L9-17841-00-00	Gear, Driven (15t)	Cylinder Head - Cylinder	1
93440-12051-00	Circlip, Outer	Cylinder Head - Cylinder	1
1L9-17811-00-00	Housing, Tachometer Gear	Cylinder Head - Cylinder	1
90201-06605-00	Washer, Plate	Cylinder Head - Cylinder	1
93109-07016-00	Oil Seal (sd0-6.5-14.5-7.0)	Cylinder Head - Cylinder	1
98503-05025-00	Screw, Pan Head Used On 168-82910-09-00 156-82920-10-94	Cylinder Head - Cylinder	1

1L9-11162-10-00	Absorber 1	Cylinder Head - Cylinder	2
1L9-11162-20-00	Absorber 2 (1L9-11162-00)	Cylinder Head - Cylinder	4
1L9-11162-30-00	Absorber 2	Cylinder Head - Cylinder	6
2A2-82590-60-00	Wire Harness Assembly	Electrical	1
2A2-82590-50-00	Wire Harness Assembly For Canada	Electrical	1
1U4-83371-20-00	Horn	Electrical	1
97301-08018-00	Bolt, Hexagon 102260~ (canada Only)	Electrical	1
92903-08100-00	Washer, Spring (92902-08100) (optional Parts)	Electrical	1
92901-08600-00	Washer, Plate Alternate Parts (u.s.a. Only)	Electrical	1
1L9-82310-51-00	Ignition Coil Assembly	Electrical	2
2A2-82310-50-00	Ignition Coil Assembly For Canada	Electrical	2
92903-06100-00	Washer, Spring Use With 214-15121-01-00 To 291-15121-00-00 Crankcase	Electrical	4
95301-06600-00	Nut, Hexagon 250 Frame #200815- 400 Frame #008894-	Electrical	4
1L9-82370-00-00	Plug Cap Assembly U. R.	Electrical	2
512-82370-10-00	Plug Cap Assembly U. R. With Noise Suppressor Alternate Parts	Electrical	2
366-82110-79-00	Battery Assembly (366-82110-60) 12n12a-4a-1	Electrical	1
118-82141-09-00	Label, Warning (104-82141-09) Alternate Parts	Electrical	1
1L9-82122-00-00	Seat, Battery	Electrical	1
122-82131-00-00	Band, Battery (116-82131-00)	Electrical	1
90445-08331-00	Hose (8-530)	Electrical	1
90386-07043-00	Bush, Special Nylon	Electrical	1
1L9-82115-01-00	Wire, Plus Lead	Electrical	1
1L9-82119-00-00	Cover, Lead Wire	Electrical	1
1L9-82116-01-00	Wire, Minus Lead	Electrical	1
1L9-82170-00-00	Fuse Box Assembly	Electrical	1
1A0-82161-00-00	Fuse (12v-20a) (148-82151-00)	Electrical	2
1A0-82151-00-00	Fuse (12v-10a)	Electrical	4
98501-05016-00	Screw, Pan Head (98506-05016)	Electrical	2
92906-05100-00	Washer, Spring For Canada	Electrical	2
92901-05600-00	Washer, Plate Alternate Parts	Electrical	2
1L9-82171-10-00	Stay, Fuse Box	Electrical	1
98501-05016-00	Screw, Pan Head (98506-05016)	Electrical	1
92903-05100-00	Washer, Spring (92901-05100) Alternate Parts	Electrical	1
92901-05600-00	Washer, Plate Alternate Parts	Electrical	1
1L9-81910-50-00	Voltage Regulator Assembly	Electrical	1
1L9-82508-41-00	Main Switch Assembly	Electrical	1
1L9-82508-50-00	Main Switch Assembly For Canada	Electrical	1
533-82517-00-00	Washer, Special	Electrical	2
98501-05018-00	Screw, Pan Head Used On 168-15411-00 222-15411-00	Electrical	2
341-82504-02-00	Oil Pressure Switch Assembly (11h-82504-00)	Electrical	1
1L9-82507-00-00	Wire, Lead	Electrical	1
1L9-82540-00-00	Neutral Switch Assembly (278-82540-01)	Electrical	1

93210-29196-00	O-Ring (2.4-29.4)	Electrical	1
98701-05012-00	Screw, Flat Head	Electrical	3
1L9-81970-60-00	Rectifier Assembly (1a0-81976-60)	Electrical	1
92503-06020-00	Screw, Pan Head (92501-06020)	Electrical	1
92903-06100-00	Washer, Spring Use With 214-15121-01-00 To 291-15121-00-00 Crankcase	Electrical	1
1J7-81940-10-00	Starter Switch Assembly U. R.	Electrical	1
1L9-82539-01-00	Stay, Stop Switch	Electrical	1
1L9-82530-00-00	Stop Switch Assembly	Electrical	1
1A0-83350-70-00	Flasher Relay Assembly Round Body	Electrical	1
1A0-83395-02-00	Flasher Cancelling Unit Assembly	Electrical	1
1L9-81625-50-00	Condenser 1	Electrical	1
92503-06010-00	Screw, Pan Head Use With 214-15121-01-00 To 291-15121-00-00 Crankcase	Electrical	1
92903-06100-00	Washer, Spring Use With 214-15121-01-00 To 291-15121-00-00 Crankcase	Electrical	1
1L9-81916-00-00	Cover, Terminal	Electrical	1
360-81950-10-00	Relay Assembly For Canada	Electrical	1
1U4-14711-00-00	Muffler, Left	Exhaust	1
1U4-14721-00-00	Muffler, Right	Exhaust	1
1L9-14788-10-00	Band, Silencer	Exhaust	1
1L9-14714-01-00	Gasket, Muffler Joint (1I9-14714-00)	Exhaust	2
91316-08025-00	Bolt, Hexagon Socket Head Cap (90110-08008)	Exhaust	2
92901-08600-00	Washer, Plate Alternate Parts (u.s.a. Only)	Exhaust	2
1L9-14611-00-00	Pipe, Exhaust Left	Exhaust	1
1L9-14621-00-00	Pipe, Exhaust Right	Exhaust	1
1L9-14612-00-00	Nut, Ring	Exhaust	2
1L9-14638-00-00	Collar	Exhaust	4
1L9-14613-00-00	Gasket, Exhaust Pipe	Exhaust	2
95301-08600-00	Nut (98801-08100) Optional Parts	Exhaust	4
95301-08600-00	Nut (98801-08100) Optional Parts	Exhaust	4
92903-08100-00	Washer, Spring (92902-08100) (optional Parts)	Exhaust	4
92903-08200-00	Washer, Plain (92901-08200) Optional Parts	Exhaust	4
371-27114-00-00	Stopper, Main Stand (usa)	Exhaust	1
1L9-14788-10-00	Band, Silencer	Exhaust	1
1L9-83320-K0-93	Front Flasher Lamp Assembly	Flasher Lamp	2
1A0-83312-K0-00	Lens, Flasher	Flasher Lamp	2
341-83313-70-00	Gasket, Flasher Lens	Flasher Lamp	2
256-83311-70-00	Bulb, Flasher (12v-25w) (183-83311-70)	Flasher Lamp	2
341-83333-70-00	Screw, Lens Fitting Screw	Flasher Lamp	4
1A0-83367-K0-00	Bolt, Stud	Flasher Lamp	2
1U4-83326-00-00	Collar, Flasher Left	Flasher Lamp	4
1E6-83321-00-00	Damper, Flasher 1	Flasher Lamp	4
1E6-83348-00-00	Washer, Special	Flasher Lamp	4
584-82519-00-00	Wire, Earth Front	Flasher Lamp	2

92903-08100-00	Washer, Spring (92902-08100) (optional Parts)	Flasher Lamp	4
95301-08600-00	Nut (98801-08100) Optional Parts	Flasher Lamp	4
1U4-83330-E0-93	Rear Flasher Lamp Assembly, Left	Flasher Lamp	1
1U4-83340-E0-93	Rear Flasher Lamp Assembly, Right	Flasher Lamp	1
1A0-83312-K0-00	Lens, Flasher	Flasher Lamp	2
341-83313-70-00	Gasket, Flasher Lens	Flasher Lamp	2
256-83311-70-00	Bulb, Flasher (12v-25w) (183-83311-70)	Flasher Lamp	2
341-83333-70-00	Screw, Lens Fitting Screw	Flasher Lamp	4
1A0-83367-K0-00	Bolt, Stud	Flasher Lamp	2
1U4-83354-00-00	Wire, Earth Lead	Flasher Lamp	1
1U4-83364-00-00	Wire, Earth Lead 300l	Flasher Lamp	1
2A2-21110-00-33	Frame Comp Yamaha Black	Frame	1
1L9-21315-00-00	Stay, Engine Rear Upper Right	Frame	1
2A2-21315-00-00	Stay, Engine Rear Upper Left	Frame	1
95822-08018-00	Bolt, Flange	Frame	4
92903-08100-00	Washer, Spring (92902-08100) (optional Parts)	Frame	4
1L9-21316-01-00	Stay, Engine Left	Frame	1
1L9-21317-01-00	Stay, Engine Right	Frame	1
1A1-15316-00-00	Damper, Engine Mount 1	Frame	2
95821-08070-00	Bolt, Flange	Frame	2
95301-08600-00	Nut (98801-08100) Optional Parts	Frame	2
92903-08100-00	Washer, Spring (92902-08100) (optional Parts)	Frame	2
95821-10145-00	Bolt, Flange	Frame	2
95821-10045-00	Bolt, Flange	Frame	2
90105-08022-00	Bolt, Engine Mounting Front (363-21482-00)	Frame	1
90170-10159-00	Nut, Hexagon	Frame	4
95301-08600-00	Nut (98801-08100) Optional Parts	Frame	1
92903-10100-00	Washer, Spring Use With Crank (l.h.) 214-11412-00-00	Frame	4
92903-08100-00	Washer, Spring (92902-08100) (optional Parts)	Frame	1
1L9-23408-00-00	Steering Lock Assembly	Frame	1
90502-09024-00	Spring, Conical (214-23485-00)	Frame	1
584-23484-01-00	Cap, Handle Lock (584-23484-00)	Frame	1
90206-04003-00	Washer, Wave (214-23483-00)	Frame	1
90269-04003-00	Rivet, Screw (214-23483-00)	Frame	1
437-83936-00-00	Band, Switch Cord (optional Parts)	Frame	1
341-26397-01-00	Band California Model	Frame	2
1L9-24183-00-00	Damper, Locating 3	Frame	2
437-83936-10-00	Band (803-82591-00)	Frame	1
1L9-25831-00-00	Disc, Rear Brake	Front Disc Brake - Caliper	1
1J3-25834-01-00	Washer, Lock (306-25834-00)	Front Disc Brake - Caliper	3
90101-08312-00	Bolt, Hexagon (90101-08307)	Front Disc Brake - Caliper	6
1L9-25810-03-00	Caliper Assembly (119-25810-02)	Front Disc Brake - Caliper	1

1L9-20000-02-00	Caliper Pad Kit	Front Disc Brake - Caliper	1
1J3-25917-00-00	Bushing, Boot	Front Disc Brake - Caliper	1
1J3-25838-00-00	Sleeve (1j3-25843-00)	Front Disc Brake - Caliper	1
90105-08092-00	Bolt, Support	Front Disc Brake - Caliper	1
1J3-W0048-00-00	Screw, Bleed With Cap (1j3-20000-30)	Front Disc Brake - Caliper	1
1J3-20000-20-00	Caliper Seal Kit	Front Disc Brake - Caliper	1
1J3-25845-01-00	Cap, Indicator E006501-f	Front Disc Brake - Caliper	1
90101-10308-00	Bolt (306-25818-00)	Front Disc Brake - Caliper	2
92903-10100-00	Washer, Spring Use With Crank (l.h.) 214-11412-00-00	Front Disc Brake - Caliper	2
92903-10200-00	Washer, Spring (92901-10200)	Front Disc Brake - Caliper	2
1A0-21510-02-93	Front Fender Comp	Front Fender - Rear Fender	1
1A0-21518-00-00	Holder, Caable	Front Fender - Rear Fender	1
90101-08253-00	Bolt, Hexagon	Front Fender - Rear Fender	4
90201-08097-00	Washer, Plate (700-48192-10)	Front Fender - Rear Fender	4
2A2-W2161-01-93	Rear Fender Comp	Front Fender - Rear Fender	1
90480-14102-00	Damper, Battery Box 1 (6.5-20-1.6) (214-21717-00)	Front Fender - Rear Fender	2
90387-07390-00	Collar (7-10-11.5) (214-21633-00)	Front Fender - Rear Fender	2
92901-06600-00	Washer, Plate Alternate Parts (u.s.a. Only)	Front Fender - Rear Fender	2
97301-06030-00	Bolt (97303-06030)	Front Fender - Rear Fender	2
95301-06600-00	Nut, Hexagon 250 Frame #200815- 400 Frame #008894-	Front Fender - Rear Fender	2
168-21638-00-00	Damper, Front	Front Fender - Rear Fender	2
90480-15061-00	Grommet 102260~ Canada	Front Fender - Rear Fender	1
1U4-21620-00-00	Mud Guard Assembly	Front Fender - Rear Fender	1
1L9-21268-00-00	Seal	Front Fender - Rear Fender	1
97301-06016-00	Bolt, Hexagon (97301-06015) Se ~114240	Front Fender - Rear Fender	2
92903-06100-00	Washer, Spring Use With 214-15121-01-00 To 291-15121-00-00 Crankcase	Front Fender - Rear Fender	2
92901-06600-00	Washer, Plate Alternate Parts (u.s.a. Only)	Front Fender - Rear Fender	2
92901-12200-00	Washer, (92902-12200)	Front Fender - Rear Fender	2
248-21635-00-00	Nut, Rear Fender	Front Fender - Rear Fender	2
97301-08018-00	Bolt, Hexagon 102260~ (canada Only)	Front Fender - Rear Fender	2
92903-08100-00	Washer, Spring (92902-08100) (optional Parts)	Front Fender - Rear Fender	2
92903-08200-00	Washer, Plain (92901-08200) Optional Parts	Front Fender - Rear Fender	2
90201-06067-00	Washer, Leg Shield 2 (6.5-20-1.6) (116-28324-00-00)	Front Fender - Rear Fender	2
122-82131-00-00	Band, Battery (116-82131-00)	Front Fender - Rear Fender	1
1L9-28100-10-00	Tool Assembly	Front Fender - Rear Fender	1
90464-16021-00	Clamp	Front Fender - Rear Fender	2
1U4-2814A-00-00	Wire, Hook	Front Fender - Rear Fender	1
1L9-23101-01-00	Front Fork Assembly	Front Fork	1
2L0-23126-00-00	Tube, Outer Left (1l9-23126-01)	Front Fork	1
1L9-23136-01-00	Tube, Outer Right	Front Fork	1
1L9-23146-00-00	Washer, Oil Seal	Front Fork	1
1L9-23145-00-00	Oil Seal	Front Fork	1

1L9-23156-00-00	Clip, Oil Seal	Front Fork	1
90116-08260-00	Bolt, Stud (1e7-23182-00)	Front Fork	1
1L9-23166-00-00	Spacer, Oil Lock	Front Fork	1
1L9-23110-01-00	Inner Tube Comp	Front Fork	1
1E7-23151-00-00	Spring, Rebound	Front Fork	1
1E7-23157-00-00	Ring, Piston Front Fork	Front Fork	1
1L9-23170-02-00	Cylinder Comp, Front Fork (1l9-23170-01)	Front Fork	1
1L9-23141-01-00	Spring, Front Fork	Front Fork	1
1L9-23144-00-00	Seal, Dust	Front Fork	1
1L9-23114-00-00	O-Ring (2.8-19.4)	Front Fork	1
1L9-23111-00-00	Seat, Spring	Front Fork	1
1L9-23183-00-00	Ring, Stopper	Front Fork	1
1L9-23168-00-00	Cap, Front Fork	Front Fork	1
1L9-23340-00-33	Under Bracket Comp	Front Fork	1
97323-10035-00	Bolt (97321-10035)	Front Fork	1
92903-10100-00	Washer, Spring Use With Crank (l.h.) 214-11412-00-00	Front Fork	1
1E7-23167-00-00	Holder, Axle	Front Fork	1
92901-08600-00	Washer, Plate Alternate Parts (u.s.a. Only)	Front Fork	1
90185-08054-00	Nut, Self-Locking (90185-08086)	Front Fork	1
1E7-23181-00-00	Bolt, Hexagon Socket Head (2y4-23181-00)	Front Fork	1
1E7-23119-00-00	Plug, Drain With Gasket	Front Fork	1
1L9-23121-01-33	Stay, Head Lamp Yamaha Black	Front Fork	1
90480-14052-00	Grommet	Front Fork	1
90387-06216-00	Collar	Front Fork	1
90201-06067-00	Washer, Leg Shield 2 (6.5-20-1.6) (116-28324-00-00)	Front Fork	1
97321-06020-00	Bolt Must Use W/kick Crank: 367-00	Front Fork	1
92903-06100-00	Washer, Spring Use With 214-15121-01-00 To 291-15121-00-00 Crankcase	Front Fork	1
90109-06005-00	Bolt, Fitting (337-84752-00)	Front Fork	1
1U4-24768-00-00	Stopper	Front Fork	4
355-85111-00-00	Reflector Front 1 (2n8-85111-00)	Front Fork	2
92901-05200-00	Washer, Plain Alternate Prts	Front Fork	2
92903-05100-00	Washer, Spring (92901-05100) Alternate Parts	Front Fork	2
1U4-25168-00-00	Cast Wheel, Front (1.85-18) (1u4-25168-20)	Front Wheel	1
94232-18115-00	Tube, Rear (3.25/3.50-18)	Front Wheel	1
94132-18379-00	Tire, Front (3.25-18-4pr)	Front Wheel	1
90560-15161-00	Spacer	Front Wheel	1
146-25115-00-00	Flange, Spacer 1 (148-25115-00)	Front Wheel	1
93306-30206-00	Bearing (b6302zz)	Front Wheel	2
93102-22014-00	Oil Seal (sd-22-42-7)	Front Wheel	1
90387-15550-00	Collar	Front Wheel	1
401-25367-00-00	Cover, Hub Dust	Front Wheel	1
92901-14200-00	Washer, Plain	Front Wheel	1

90171-14020-00	Nut, Wheel Shaft (214-25182-01)	Front Wheel	1
1U4-25847-00-00	Cover, Housing	Front Wheel	1
341-25149-00-00	Clutch, Meter	Front Wheel	1
341-25846-00-00	Retainer, Clutch Meter	Front Wheel	1
341-25137-00-00	Ring, Stop	Front Wheel	1
90201-25286-00	Shim, Cam Shaft (12.2-22-0.5) (137-25153-00)	Front Wheel	1
341-25135-01-00	Gear, Drive (29t)	Front Wheel	1
90201-25490-00	Washer, Gear Hold (2) (25-32-1) (152-17226-00)	Front Wheel	1
93105-45017-00	Oil Seal (sdd-45-56-6)	Front Wheel	1
404-25191-00-00	Housing, Gear Unit	Front Wheel	1
306-25138-00-00	Gear, Meter (10t)	Front Wheel	1
102-18416-00-00	Shim, Rod (6.2-9.5-0.8)	Front Wheel	1
306-25136-00-00	Bushing	Front Wheel	1
91609-20014-00	Pin, Spring Un	Front Wheel	1
1L9-25181-00-00	Shaft, Wheel	Front Wheel	1
91401-30030-00	Pin, Cotter (91401-30022) Original	Front Wheel	1
1A1-25398-01-00	Balancer, Wheel (1a1-25398-00) U.n. 20g	Front Wheel	0
1A1-25399-00-00	Balancer, Wheel (10g) U. N.	Front Wheel	0
1L9-24110-00-X2	Fuel Tank Comp Carmine Red	Fuel Tank	1
1L9-24244-10-00	Graphic, Fuel Tank Under Left	Fuel Tank	1
1L9-24245-10-00	Graphic, Fuel Tank Under Right	Fuel Tank	1
1L9-24246-10-00	Graphic, Fuel Tank Upper Left	Fuel Tank	1
1L9-24247-10-00	Graphic, Fuel Tank Upper Right	Fuel Tank	1
1H2-24161-00-00	Emblem, Fuel Tank	Fuel Tank	2
90249-03123-00	Pin, Special Shape	Fuel Tank	1
93430-02001-00	Circlip (e-1.9)	Fuel Tank	1
1L9-24602-00-00	Fuel Tank Cap Assembly	Fuel Tank	1
98501-05010-00	Screw, Pan Head (98503-05008) Used On 235-15411-00	Fuel Tank	1
92903-05100-00	Washer, Spring (92901-05100) Alternate Parts	Fuel Tank	1
1L9-24181-00-00	Damper, Locating Front 1	Fuel Tank	2
1L9-24182-00-00	Damper, Tank Locating	Fuel Tank	1
90209-08098-00	Washer, Special 2 (341-83348-00)	Fuel Tank	1
92903-08100-00	Washer, Spring (92902-08100) (optional Parts)	Fuel Tank	1
97301-08018-00	Bolt, Hexagon 102260~ (canada Only)	Fuel Tank	1
1L9-24500-01-00	Fuel Cock Assembly (119-24500-00)	Fuel Tank	1
1J7-24512-00-00	Gasket, Flange	Fuel Tank	1
1J7-24524-00-00	Lever, Fuel Cock Left	Fuel Tank	1
1J7-24518-00-00	Spring, Plate	Fuel Tank	1
1J7-24525-00-00	Plate, Lever Fitting Left	Fuel Tank	1
98601-03010-00	Screw, Oval Head	Fuel Tank	2
1J7-24534-00-00	Seal, Fuel Cock	Fuel Tank	1
1J7-24523-00-00	Gasket, Fuel Cock	Fuel Tank	1

1J7-24514-02-00	Filter, Fuel Cock	Fuel Tank	1
1L9-24521-00-00	Cover, Fuel Cock Drain	Fuel Tank	1
1J7-24522-00-00	Gasket, Drain Cover	Fuel Tank	1
98601-04008-00	Screw (122-23119-01)	Fuel Tank	4
90202-06010-00	Washer, Protector (6.2-12-1.5) (178-14766-00)	Fuel Tank	2
90149-06008-00	Bolt, Cock Connecting (366-24143-00) 4	Fuel Tank	2
90445-07177-00	Hose (4.2-310) (395-14197-00)	Fuel Tank	1
90445-10133-00	Pipe, Fuel (6-135) (824-24315-00)	Fuel Tank	1
90467-07029-00	Clip, Hose (806-24356-00)	Fuel Tank	2
90467-09006-00	Clip California Model Only	Fuel Tank	2
1J7-26111-00-00	Handlebar	Handle - Wire	1
1E6-26241-00-00	Grip, Left (1v1-26241-00)	Handle - Wire	1
1L9-83973-00-98	Switch, Handle 3 Left Low Gloss Black	Handle - Wire	1
1J3-82910-00-00	Lever Holder Assembly, Left	Handle - Wire	1
341-82911-00-00	Holder, Lever Left Low Gloss Black	Handle - Wire	1
1J3-83912-10-00	Lever, Left	Handle - Wire	1
97301-06022-00	Bolt, Hexagon	Handle - Wire	1
90109-06410-00	Bolt, Lever	Handle - Wire	1
95601-06100-00	Nut, U Optional Equipment	Handle - Wire	1
92903-06100-00	Washer, Spring Use With 214-15121-01-00 To 291-15121-00-00 Crankcase	Handle - Wire	1
90201-08083-00	Washer, Pedal Link (8.2-13-0.6) (156-27226-00)	Handle - Wire	1
1A8-83963-00-98	Switch, Handle 3 Right Low Gloss Black	Handle - Wire	1
1A0-26242-01-00	Grip, Right (1v1-26242-01)	Handle - Wire	1
278-26249-00-00	Ring, Leaf	Handle - Wire	1
584-26243-00-00	Tube, Throttle Guide	Handle - Wire	1
1L9-26311-00-00	Wire, Throttle (780mm)	Handle - Wire	1
584-26393-01-00	Heater Assembly Model Only Ur Cal. Only	Handle - Wire	1
1L9-26335-00-00	Wire, Clutch (1100mm)	Handle - Wire	1
90123-08046-00	Bolt, Wire Adjusting (90123-08053) Alternate Parts	Handle - Wire	1
90179-08148-00	Nut, Wire Adjusting (168-26344-00)	Handle - Wire	1
437-83936-00-00	Band, Switch Cord (optional Parts)	Handle - Wire	4
1J7-26290-12-00	Back Mirror Assembly, Left (1j7-26290-11)	Handle - Wire	1
1J7-26290-11-00	Back Mirror Assembly, Left	Handle - Wire	1
1J7-26290-02-00	Mirror Assembly Rh (1j7-26290-0 Optional Part	Handle - Wire	1
1J7-26290-01-00	Back Mirror Assembly, Right Optional Parts	Handle - Wire	1
1L9-84330-61-33	Head Lamp Body Assembly Yamaha Black	Head Lamp	1
1L9-84338-60-00	Collar, Body Fitting	Head Lamp	2
1L9-84366-61-00	Damper, Headlight 1	Head Lamp	2
1L9-84367-61-00	Damper, Headlight 2	Head Lamp	2
1L9-84327-60-00	Collar, Body Fitting	Head Lamp	2
1L9-84310-60-00	Head Lamp Unit Assembly	Head Lamp	1
1L9-84315-60-00	Rim, Headlight	Head Lamp	1

1L9-84320-60-00	Lens Assembly	Head Lamp	1
1L9-84331-60-00	Screw, Rim Adjusting Optional Part	Head Lamp	1
1L9-84332-60-00	Spring, Screw Optional Part	Head Lamp	1
92901-04600-00	Washer, Spring (92901-04100-00)	Head Lamp	1
1L9-84334-60-00	Nut, Adjusting Optional Part	Head Lamp	1
92503-06010-00	Screw, Pan Head Use With 214-15121-01-00 To 291-15121-00-00 Crankcase	Head Lamp	2
92903-06100-00	Washer, Spring Use With 214-15121-01-00 To 291-15121-00-00 Crankcase	Head Lamp	2
95301-06600-00	Nut, Hexagon 250 Frame #200815- 400 Frame #008894-	Head Lamp	2
98503-05015-00	Screw, Pan Head Oil Pump Assembly Refer To M8-0150	Head Lamp	2
92903-05100-00	Washer, Spring (92901-05100) Alternate Parts	Head Lamp	2
97303-08035-00	Bolt, Hexagon (97304-08035)	Head Lamp	2
92903-08200-00	Washer, Plain (92901-08200) Optional Parts	Head Lamp	2
92903-08100-00	Washer, Spring (92902-08100) (optional Parts)	Head Lamp	2
95301-08600-00	Nut (98801-08100) Optional Parts	Head Lamp	2
1L9-13556-00-00	Gasket, Manifold	Intake	2
2A2-13586-00-00	Joint, Carburetor Left	Intake	1
2A2-13596-00-00	Joint, Carburetor Right	Intake	1
91316-06020-00	Bolt, Hexagon Socket Head (91318-06020)	Intake	4
90460-51131-00	Clamp, Hose	Intake	2
1J7-13569-00-00	Plug, Blind	Intake	1
90460-58124-00	Clamp, Hose (usa)	Intake	2
2A2-14453-00-00	Joint 1	Intake	2
90413-40002-00	Way, 3	Intake	1
90460-45040-00	Clamp, Hose (90460-45104)	Intake	2
90460-49058-00	Clamp, Hose (278-14455-00) 2	Intake	2
90480-50194-00	Grommet	Intake	2
2A2-14411-00-00	Case, Air Cleaner 1	Intake	2
1L9-14451-00-00	Element, Air Cleaner	Intake	2
2A2-14421-00-00	Case, Air Cleaner 2	Intake	2
98503-04015-00	Screw, Pan Head (305-14567-00-33)	Intake	4
92901-04600-00	Washer, Spring (92901-04100-00)	Intake	4
1L9-15660-00-00	Kick Axle Assembly	Kickstarter	1
136-17417-00-10	Shim, Main Axle (17.2-28-1)	Kickstarter	1
371-15641-01-00	Gear, Kick (23t)	Kickstarter	1
90468-26045-00	Clip (278-15687-00)	Kickstarter	1
278-15676-00-00	Cover, Kick Spring	Kickstarter	1
90508-30051-00	Spring, Torsion (278-15665-00)	Kickstarter	1
371-15666-00-00	Spacer	Kickstarter	1
93410-20009-00	Circlip (21.2-29-2)	Kickstarter	1
90201-20266-00	Washer, Gear Hold (20-25-1) (132-17216-00-00)	Kickstarter	1
93102-20108-00	Oil Seal Alternate Part	Kickstarter	1
278-15621-00-00	Boss, Kick Crank Alternate Part	Kickstarter	1

97321-08030-00	Bolt, Hexagon	Kickstarter	1
1L9-15611-01-93	Crank, Kick (119-15611-00-93)	Kickstarter	1
93507-32009-00	Ball (7/32 Inch) 1	Kickstarter	1
90501-12081-00	Spring, Boss Stopper (278-15622-00)	Kickstarter	1
90201-15340-00	Washer, Special (15.5-25-1.6)	Kickstarter	1
93430-10016-00	Clip Optional, Right Change, Left Brake Part	Kickstarter	1
156-15618-01-00	Cover, Kick Lever Alternate Part	Kickstarter	1
1J3-25850-02-00	Master Cylinder Assembly Front (1j3-25850-01) Nishin	Master Cylinder - Brake Hose	1
535-20000-60-00	Cylinder Kit, Master Cylinder	Master Cylinder - Brake Hose	1
1J3-25852-01-00	Reservoir Cap Assembly	Master Cylinder - Brake Hose	1
1J3-25855-01-00	Bushing, Diaphragm	Master Cylinder - Brake Hose	1
1J3-25854-01-00	Diaphragm, Reservoir	Master Cylinder - Brake Hose	1
90151-05008-00	Screw, Cross Recess	Master Cylinder - Brake Hose	4
1J3-25867-00-00	Bracket, Master (360-25867-01) Frosting Black	Master Cylinder - Brake Hose	1
97321-06025-00	Bolt, Hexagon Must Use W/kick Crank: 367-01	Master Cylinder - Brake Hose	2
92903-06100-00	Washer, Spring Use With 214-15121-01-00 To 291-15121-00-00 Crankcase	Master Cylinder - Brake Hose	2
90338-09012-00	Plug, Blind (341-26329-00)	Master Cylinder - Brake Hose	1
1J3-83922-10-00	Lever, Right	Master Cylinder - Brake Hose	1
90149-06131-00	Screw, Oval Head (90146-06008)	Master Cylinder - Brake Hose	1
90170-06010-00	Nut, Adjusting (306-83917-00) Pn330	Master Cylinder - Brake Hose	1
90501-10312-00	Spring, Lever Return (306-83924-00)	Master Cylinder - Brake Hose	1
90109-06465-00	Screw, Lever Fitting (341-83925-00)	Master Cylinder - Brake Hose	1
95601-06100-00	Nut, U Optional Equipment	Master Cylinder - Brake Hose	1
90201-10118-00	Washer, Oil Bolt (10.2-14-1.0) (306-25878-00)	Master Cylinder - Brake Hose	4
90401-10034-00	Bolt, Union (90201-10118)	Master Cylinder - Brake Hose	2
360-25862-00-00	Boot, Master Cylinder Canada Alternate Parts Only (bar Handle)	Master Cylinder - Brake Hose	1
2A2-25872-00-00	Hose, Brake	Master Cylinder - Brake Hose	1
1L9-25876-00-00	Holder, Brake Hose 2	Master Cylinder - Brake Hose	1
97301-06025-00	Bolt, Hexagon (97302-06025)	Master Cylinder - Brake Hose	1
92903-06100-00	Washer, Spring Use With 214-15121-01-00 To 291-15121-00-00 Crankcase	Master Cylinder - Brake Hose	1
1A0-83980-30-00	Front Stop Switch Assembly 1	Master Cylinder - Brake Hose	1
1L9-13300-00-00	Oil Pump Assembly	Oil Pump - Oil Cleaner	1
1L9-13483-00-00	Plunger, Relief	Oil Pump - Oil Cleaner	1
1L9-13484-00-00	Spring, Relief	Oil Pump - Oil Cleaner	1
1L9-13486-00-00	Retainer, Relief Valve	Oil Pump - Oil Cleaner	1
91401-25030-00	Pin, Cotter (91401-25025)	Oil Pump - Oil Cleaner	1
1L9-13341-01-00	Gear, Oil Pump Idle (32t/20t)	Oil Pump - Oil Cleaner	1
91318-08035-00	Bolt, Hexagon Socket Head	Oil Pump - Oil Cleaner	2
91830-21014-00	Pin, Dowel (6.4-10-14) (91810-02014)	Oil Pump - Oil Cleaner	1
1L9-13411-00-00	Strainer, Oil	Oil Pump - Oil Cleaner	1
1L9-13414-00-00	Gasket, Strainer Cover	Oil Pump - Oil Cleaner	1
1L9-13417-00-00	Cover, Strainer	Oil Pump - Oil Cleaner	1

97301-05015-00	Bolt, Hexagon	Oil Pump - Oil Cleaner	6
92901-05600-00	Washer, Plate Alternate Parts	Oil Pump - Oil Cleaner	6
93210-88324-00	O-Ring (4.1-87.8)	Oil Pump - Oil Cleaner	1
1L9-13440-90-00	Element, Oil Filter (1L9-13441-10)	Oil Pump - Oil Cleaner	1
90480-23193-00	Grommet	Oil Pump - Oil Cleaner	2
90201-21608-00	Washer, Plate	Oil Pump - Oil Cleaner	1
90501-20422-00	Spring, Compression	Oil Pump - Oil Cleaner	1
1L9-13447-00-00	Cover, Element	Oil Pump - Oil Cleaner	1
90401-20043-00	Bolt, Union	Oil Pump - Oil Cleaner	1
93210-16325-00	O-Ring (2.4-15.8)	Oil Pump - Oil Cleaner	1
1L9-13345-00-00	Piston, By-Pass Valve	Oil Pump - Oil Cleaner	1
90501-10421-00	Spring, Compression	Oil Pump - Oil Cleaner	1
91609-20018-00	Pin, Spring	Oil Pump - Oil Cleaner	1
91318-08045-00	Bolt, Hexagon Socket Head	Oil Pump - Oil Cleaner	1
1U4-22110-00-33	Rear Arm Comp Yamaha Black	Rear Arm - Rear Cushion	1
90387-16398-00	Bushing 2 (322-22124-00)	Rear Arm - Rear Cushion	1
90386-22029-00	Bushing, Rear Arm (256-22123-01)	Rear Arm - Rear Cushion	2
240-22127-00-00	Shim, Rear Arm (26-34-0.3) (156-22127-00) U. N.	Rear Arm - Rear Cushion	0
371-22128-00-00	Cover, Thrust 1 (371-22128-01)	Rear Arm - Rear Cushion	2
1L9-22141-00-00	Shaft, Pivot	Rear Arm - Rear Cushion	1
90215-14113-00	Washer, Lock (256-22149-00)	Rear Arm - Rear Cushion	1
90170-14174-00	Nut, Hexagon	Rear Arm - Rear Cushion	1
1L9-22210-00-00	Shock Absorber Assembly, Rear	Rear Arm - Rear Cushion	2
90201-10140-00	Washer, Rear Cushion (10.5-27-2) (136-22243-00)	Rear Arm - Rear Cushion	2
90176-10013-00	Nut, Crown (90176-10027)	Rear Arm - Rear Cushion	2
90106-10025-00	Bolt, Rear Cushion (214-22241-00) Alternate Parts	Rear Arm - Rear Cushion	2
1L9-22311-00-33	Case, Chain Yamaha Black	Rear Arm - Rear Cushion	1
278-22332-00-00	Damper, Chain Case	Rear Arm - Rear Cushion	1
90387-07389-00	Collar, Fender Mount (256-21544-00)	Rear Arm - Rear Cushion	1
90209-06034-00	Washer, Chain Case (278-22316-00)	Rear Arm - Rear Cushion	1
92903-06100-00	Washer, Spring Use With 214-15121-01-00 To 291-15121-00-00 Crankcase	Rear Arm - Rear Cushion	2
97301-06018-00	Bolt, Hexagon 005001~ M7-021	Rear Arm - Rear Cushion	2
1L9-25831-00-00	Disc, Rear Brake	Rear Disc Brake - Caliper	1
1J3-25834-01-00	Washer, Lock (306-25834-00)	Rear Disc Brake - Caliper	3
90101-08312-00	Bolt, Hexagon (90101-08307)	Rear Disc Brake - Caliper	6
1U4-25810-51-00	Caliper Assembly, Rear (1u4-25810-50)	Rear Disc Brake - Caliper	1
1U4-W0046-02-00	Caliper Pad Kit (1u4-W0046-01)	Rear Disc Brake - Caliper	1
1J3-25917-00-00	Bushing, Boot	Rear Disc Brake - Caliper	1
1J3-25838-00-00	Sleeve (1j3-25843-00)	Rear Disc Brake - Caliper	1
90105-08092-00	Bolt, Support	Rear Disc Brake - Caliper	1
1J3-W0048-00-00	Screw, Bleed With Cap (1j3-20000-30)	Rear Disc Brake - Caliper	1
1J3-20000-20-00	Caliper Seal Kit	Rear Disc Brake - Caliper	1

1J3-25845-01-00	Cap, Indicator E006501-/f	Rear Disc Brake - Caliper	1
90109-08454-00	Bolt, Special	Rear Disc Brake - Caliper	1
90206-12034-00	Washer, Wave (826-18195-00)	Rear Disc Brake - Caliper	1
92901-08600-00	Washer, Plate Alternate Parts (u.s.a. Only)	Rear Disc Brake - Caliper	1
92903-08100-00	Washer, Spring (92902-08100) (optional Parts)	Rear Disc Brake - Caliper	1
90170-08158-00	Nut (90170-08260)	Rear Disc Brake - Caliper	1
91401-20015-00	Pin, Cotter (2-12) (91451-20012)	Rear Disc Brake - Caliper	1
1U4-W2533-20-00	Cast Wheel, Rear (2.15-18)	Rear Wheel	1
94232-18115-00	Tube, Rear (3.25/3.50-18)	Rear Wheel	1
94135-18360-00	Tire, Rear (3.50-18-4pr) Tire, Rear (3.50-18-4pr) U. R. Bridgestone Yokohama	Rear Wheel	1
1J3-25317-00-00	Spacer, Bearing	Rear Wheel	1
1A1-25115-00-00	Flange, Spacer (148-25315-00)	Rear Wheel	1
1A1-25377-00-00	Collar, Wheel	Rear Wheel	1
93306-30417-00	Bearing (b6304zz)	Rear Wheel	1
93104-27026-00	Oil Seal (s0-27-52-5)	Rear Wheel	1
93306-30309-00	Bearing (b6303z) (93306-30303-00)	Rear Wheel	1
93102-28022-00	Oil Seal (sd-28-47-7)	Rear Wheel	1
90387-17536-00	Collar	Rear Wheel	1
1J3-25118-00-00	Cover, Hub Dust	Rear Wheel	1
168-25389-00-00	Puller, Chain (r.h.) (170)	Rear Wheel	2
95301-08700-00	Nut (92801-08300) For Folding Footrest	Rear Wheel	2
90101-08034-00	Bolt, Chain Puller (168-25379-00)	Rear Wheel	2
1J3-25381-00-00	Axle, Wheel (2v6-25381-00)	Rear Wheel	1
91401-30030-00	Pin, Cotter (91401-30022) Original	Rear Wheel	1
90387-20565-00	Collar (23.5-35.5-5.5)	Rear Wheel	4
1J3-25437-20-00	Gear, Sprocket Wheel (37t)	Rear Wheel	1
1J3-25412-00-00	Washer, Plate	Rear Wheel	2
95301-12700-00	Nut, Rear Footrest (206-27436-00) Iso	Rear Wheel	4
94580-10098-00	Chain (did50ds-98l)	Rear Wheel	1
94685-30011-00	Joint, Chain	Rear Wheel	1
90201-66585-00	Washer, Plate	Rear Wheel	1
93410-65040-00	Circlip, S-Type	Rear Wheel	1
90387-17551-00	Collar, Wheel Shaft	Rear Wheel	1
1L9-25367-00-00	Cover, Hub Dust	Rear Wheel	1
92901-14200-00	Washer, Plain	Rear Wheel	1
90171-14020-00	Nut, Wheel Shaft (214-25182-01)	Rear Wheel	1
1A1-25398-01-00	Balancer, Wheel (1al-25398-00) U.n. 20g	Rear Wheel	0
1A1-25399-00-00	Balancer, Wheel (10g) U. N.	Rear Wheel	0
1U4-24730-90-00	Double Seat Assembly	Seat	1
1U4-24731-01-00	Cover, Double Seat	Seat	1
1U4-24756-00-E9	Cover, Tail Carmine Red	Seat	1
92901-05200-00	Washer, Plain Alternate Prts	Seat	3

92906-05100-00	Washer, Spring For Canada	Seat	3
95306-05600-00	Nut, Hexagon	Seat	3
97301-05016-00	Bolt, Hexagon (97301-05015)	Seat	2
92903-05100-00	Washer, Spring (92901-05100) Alternate Parts	Seat	2
92901-05600-00	Washer, Plate Alternate Parts	Seat	2
2A2-24786-00-00	Emblem	Seat	1
1L9-24741-00-00	Pad, Seat (174-24741-00) Optional Parts	Seat	3
371-27114-00-00	Stopper, Main Stand (usa)	Seat	1
1L9-24769-00-00	Hinge, Seat	Seat	1
1L9-24726-02-00	Hinge, Seat	Seat	1
1J7-24723-00-00	Damper, Seat (119-24723-00)	Seat	4
90387-07390-00	Collar (7-10-11.5) (214-21633-00)	Seat	4
1L9-24746-00-00	Washer, Seat Hinge	Seat	2
92903-06100-00	Washer, Spring Use With 214-15121-01-00 To 291-15121-00-00 Crankcase	Seat	4
97301-06025-00	Bolt, Hexagon (97302-06025)	Seat	4
91701-05055-00	Pin, Clevis (91501-05055)	Seat	2
90468-10050-00	Clip (156-83525-00)	Seat	2
371-24728-01-00	Bracket, Seat	Seat	1
92903-06100-00	Washer, Spring Use With 214-15121-01-00 To 291-15121-00-00 Crankcase	Seat	2
97301-06012-00	Bolt, Hexagon (91201-06012)	Seat	2
1L9-24705-00-00	Seat Lock Assembly	Seat	1
92603-06012-00	Screw, Flat Head Dt100e/e0l1001-f	Seat	2
341-28185-00-00	Lid	Seat	1
90480-06007-00	Grommet (341-28187-00)	Seat	1
341-28188-00-00	Plunger	Seat	1
1L9-24785-00-E9	Mold, Double Seat Left Carmine Red	Seat	1
1L9-24785-10-E9	Mold, Double Seat Right Carmine Red	Seat	1
90183-04012-00	Nut, Spring (116-28317-01)	Seat	4
1L9-24789-00-00	Rivet	Seat	4
1J7-24777-00-00	Bolt, Lever Fitting	Seat	4
1J7-24722-00-00	Washer, Special	Seat	4
95301-04600-00	Nut (92801-04100) Used On 168-84311-01-22	Seat	4
92901-04200-00	Washer, Plate (119-81655-50)	Seat	4
2A2-24757-00-00	Graphic, Tail Cover Left	Seat	1
2A2-24767-00-00	Graphic, Tail Cover Right	Seat	1
360-18541-00-00	Cam, Shift	Shifter	1
93315-23612-00	Bearing, Cylindrical (93315-23607)	Shifter	1
328-18185-00-00	Segment	Shifter	1
93604-14012-00	Pin, Dowel (4.0-13.8)	Shifter	1
93604-22050-00	Pin, Dowel (40-22) 514910~	Shifter	6
328-18561-00-00	Plate, Side 1	Shifter	1
98701-05020-00	Screw, Flat Head	Shifter	1

328-18352-10-00	Inactive Part Number	Shifter	1
1L9-18141-00-00	Plate, Stopper	Shifter	1
93410-30012-00	Circlip (s-30) (yg9-00006-35-1g)	Shifter	1
278-18566-00-00	Plate, Side 2	Shifter	1
90501-06022-00	Spring, Compression (278-18545-00)	Shifter	1
278-18542-00-00	Point, Neutral	Shifter	1
98701-05012-00	Screw, Flat Head	Shifter	1
93604-08071-00	Pin, Dowel (4.0-8.0)	Shifter	1
328-18562-00-00	Plate, Stopper 2	Shifter	1
92701-06015-00	Screw, Flat Head	Shifter	2
328-18179-00-00	Guide, Change Lever	Shifter	1
98501-05010-00	Screw, Pan Head (98503-05008) Used On 235-15411-00	Shifter	2
328-18511-01-00	Fork, Shift 1 (328-18511-00)	Shifter	2
328-18512-01-00	Fork, Shift 2 (328-18512-00)	Shifter	2
90250-08017-00	Pin, Cam Follower (278-18552-00) Lt3 066631~ Ltmx 113021~	Shifter	4
91401-25020-00	Pin, Cotter (91401-25012)	Shifter	4
278-18531-00-00	Bar, Shift Fork Guide 1	Shifter	1
278-18535-00-00	Bar, Shift Fork Guide 2	Shifter	1
93430-10016-00	Clip Optional, Right Change, Left Brake Part	Shifter	4
90338-22021-00	Plug, Special Shape (371-18149-	Shifter	2
278-18547-02-00	Stopper, Cam (278-18547-01)	Shifter	1
90501-10062-00	Spring, Compression (278-18557-00)	Shifter	1
137-15353-00-00	Gasket, Drain Plug (14.0-21.0-1.5)	Shifter	1
90149-14031-00	Screw (278-18577-03)	Shifter	1
328-18128-00-00	Bracket	Shifter	1
90508-08007-00	Spring, Torsion (214-18123-00)	Shifter	1
328-18151-00-00	Lever, Change 3	Shifter	2
93430-07012-00	Circlip (e-7)	Shifter	1
214-18178-00-00	Roller, Change Lever (1)	Shifter	1
90149-06017-00	Screw, Adjusting (214-18186-00) E/#1 1572-	Shifter	1
95301-06600-00	Nut, Hexagon 250 Frame #200815- 400 Frame #008894-	Shifter	1
92903-06100-00	Washer, Spring Use With 214-15121-01-00 To 291-15121-00-00 Crankcase	Shifter	1
90508-32055-00	Spring, Shaft Return (278-18124-00)	Shifter	1
278-18127-00-00	Screw, Adjusting	Shifter	1
90215-08015-00	Washer, Lock (214-18139-00) M4-046	Shifter	1
278-18101-01-00	Shift Shaft Assembly 1	Shifter	1
93102-12106-00	Oil Seal (s-12-22-5) (93101-12004)	Shifter	1
90201-12575-00	Washer, Change Shaft (12-25.5-1.5) (137-18137-00)	Shifter	1
93430-10016-00	Clip Optional, Right Change, Left Brake Part	Shifter	1
278-18131-00-00	Boot, Sealing	Shifter	1
2L1-18111-00-00	Pedal, Change (119-18111-02-93)	Shifter	1
97321-06020-00	Bolt Must Use W/kick Crank: 367-00	Shifter	1

132-18113-01-00	Cover, Change Pedal (132-18113-00)	Shifter	1
1L9-21711-00-E9	Cover, Side Left Carmine Red	Side Cover - Battery Box	1
1L9-21721-00-E9	Cover, Side Right Carmine Red	Side Cover - Battery Box	1
90480-12053-00	Grommet, Side Cover	Side Cover - Battery Box	4
90480-01141-00	Damper, Side Cover 2 (371-21747-00)	Side Cover - Battery Box	2
2A2-21784-00-00	Emblem, Side Cover Left	Side Cover - Battery Box	1
2A2-21786-00-00	Emblem, Side Cover Right	Side Cover - Battery Box	1
1L9-21240-00-33	Box, Battery Yamaha Black	Side Cover - Battery Box	1
90480-14102-00	Damper, Battery Box 1 (6.5-20-1.6) (214-21717-00)	Side Cover - Battery Box	2
90387-07390-00	Collar (7-10-11.5) (214-21633-00)	Side Cover - Battery Box	2
90201-06067-00	Washer, Leg Shield 2 (6.5-20-1.6) (116-28324-00-00)	Side Cover - Battery Box	2
97301-06025-00	Bolt, Hexagon (97302-06025)	Side Cover - Battery Box	1
97301-06020-00	Bolt (91201-06020)	Side Cover - Battery Box	1
90480-22196-00	Grommet	Side Cover - Battery Box	1
1L9-21776-01-00	Band, Tank Fitting	Side Cover - Battery Box	2
92501-06030-00	Screw Pan Head (92501-06030-00)	Side Cover - Battery Box	2
92901-06600-00	Washer, Plate Alternate Parts (u.s.a. Only)	Side Cover - Battery Box	2
1L9-82126-01-00	Pad, Battery (119-82126-00)	Side Cover - Battery Box	4
1L9-83519-01-98	Bracket, Meter Low Gloss Black	Speedometer - Tachometer	1
1J3-83568-71-00	Pilot Box, Upper 006301-	Speedometer - Tachometer	1
1J3-83569-71-00	Pilot Box, Lower (1j7-83569-71)	Speedometer - Tachometer	1
98506-04020-00	Screw, Pan Head 006301-	Speedometer - Tachometer	4
92906-04100-00	Washer, Spring 006301-	Speedometer - Tachometer	4
92906-04600-00	Washer, Plate	Speedometer - Tachometer	4
98501-05010-00	Screw, Pan Head (98503-05008) Used On 235-15411-00	Speedometer - Tachometer	1
1A0-83570-41-00	Speedometer Assembly Mile/h	Speedometer - Tachometer	1
1A2-83570-21-00	Speedometer Assembly For Canada Km/h	Speedometer - Tachometer	1
584-83578-71-00	Knob, Trip Meter	Speedometer - Tachometer	1
123-83516-21-00	Bulb, Pilot (15v-3w) (123-83516-20)	Speedometer - Tachometer	2
1L9-83536-01-00	Socket Cord Assembly, Speedometer	Speedometer - Tachometer	1
1A0-83556-01-00	Socket Cord Assembly	Speedometer - Tachometer	1
1L9-83540-01-00	Tachometer Assembly	Speedometer - Tachometer	1
123-83516-21-00	Bulb, Pilot (15v-3w) (123-83516-20)	Speedometer - Tachometer	3
1L9-83520-01-00	Socket Cord Assembly, Tachometer	Speedometer - Tachometer	1
1A0-83513-00-00	Damper, Meter	Speedometer - Tachometer	2
1A0-83507-00-00	Cover, Speedometer	Speedometer - Tachometer	1
1A0-83508-00-00	Cover, Tachometer	Speedometer - Tachometer	1
1A0-83522-00-00	Collar	Speedometer - Tachometer	4
584-83523-00-00	Damper, Meter Cover Fitting	Speedometer - Tachometer	4
90201-05031-00	Washer, Special (5.5-15-1.0) (256-82517-00)	Speedometer - Tachometer	4
95303-05800-00	Nut, Crown (95304-05800)	Speedometer - Tachometer	4
584-83546-00-00	Bolt	Speedometer - Tachometer	4

92903-06200-00	Washer, Push Lever (6.2-15-1) (122-16359-00)	Speedometer - Tachometer	4
92903-06100-00	Washer, Spring Use With 214-15121-01-00 To 291-15121-00-00 Crankcase	Speedometer - Tachometer	4
95303-06800-00	Nut, Crown (95301-06800)	Speedometer - Tachometer	4
1L9-83509-71-00	Socket Cord Assembly, Indicator Lamp	Speedometer - Tachometer	1
123-83516-21-00	Bulb, Pilot (15v-3w) (123-83516-20)	Speedometer - Tachometer	4
90381-08024-00	Bush, Solid	Speedometer - Tachometer	2
90201-06067-00	Washer, Leg Shield 2 (6.5-20-1.6) (116-28324-00-00)	Speedometer - Tachometer	2
92903-06100-00	Washer, Spring Use With 214-15121-01-00 To 291-15121-00-00 Crankcase	Speedometer - Tachometer	2
95301-06600-00	Nut, Hexagon 250 Frame #200815- 400 Frame #008894-	Speedometer - Tachometer	2
351-83550-00-00	Speedometer Assembly	Speedometer - Tachometer	1
351-83550-01-00	Speedometer Assembly	Speedometer - Tachometer	1
1L9-83560-01-00	Tachometer Cable Assembly (119-83560-00)	Speedometer - Tachometer	1
1L9-27111-01-00	Stand, Main	Stand - Footrest	1
90109-10221-00	Bolt, Main Stand	Stand - Footrest	2
95601-10100-00	Nut, U (95602-10100-00) 1	Stand - Footrest	2
90506-45063-00	Spring, Tension (168-27116-00)	Stand - Footrest	1
1L9-27311-00-00	Stand, Side	Stand - Footrest	1
90102-10006-00	Bolt, Side Stand Use With Frame Comp 1j7-21110-01-33	Stand - Footrest	1
90171-10012-00	Nut, Castle (92802-10500)	Stand - Footrest	1
91490-20025-00	Pin, Cotter (91403-20025) (91401-20025)	Stand - Footrest	1
90506-28100-00	Spring, Tension (276-27316-00)	Stand - Footrest	1
1T4-27314-00-00	Stopper, Side Stand	Stand - Footrest	1
2L0-27410-00-00	Footrest Assembly, Left (119-27410-01)	Stand - Footrest	1
2L0-27420-00-00	Footrest Assembly, Right (119-27420-01)	Stand - Footrest	1
1J7-27413-01-00	Cover, Footrest Right	Stand - Footrest	2
1T3-27451-00-00	Bracket, Footrest Left	Stand - Footrest	1
1T3-27461-00-00	Bracket, Footrest Right	Stand - Footrest	1
90508-20023-00	Spring, Return (214-27418-00) Pn253	Stand - Footrest	2
90243-08006-00	Pin, Clevis (214-47418-00) Pn253	Stand - Footrest	2
90201-06042-00	Washer, Special (6.5-12-2.0) (214-27417-00)	Stand - Footrest	2
90480-20195-00	Grommet	Stand - Footrest	4
97321-08016-00	Bolt, Hexagon (97321-08015)	Stand - Footrest	4
92903-08100-00	Washer, Spring (92902-08100) (optional Parts)	Stand - Footrest	4
90209-08150-00	Washer, Special Shape (90209-080	Stand - Footrest	4
90209-12157-00	Washer, Special Shape	Stand - Footrest	4
1U4-27432-00-00	Bracket, Rear Footrest Left	Stand - Footrest	1
1U4-27442-00-00	Bracket, Rear Footrest Right	Stand - Footrest	1
447-27433-00-00	Cover, Right Rear Footrest	Stand - Footrest	2
447-27431-00-00	Footrest, Rear Left	Stand - Footrest	1
447-27441-00-00	Footrest, Rear 2 (447-27441-01)	Stand - Footrest	1
90209-18070-00	Washer, Plate (447-27437-00)	Stand - Footrest	2
91501-06035-00	Pin, Clevis (6-35) Folding Type	Stand - Footrest	2

91401-16015-00	Pin, Cotter Alternate Parts	Stand - Footrest	2
95701-10100-00	Nut, Flange	Stand - Footrest	2
92903-10100-00	Washer, Spring Use With Crank (l.h.) 214-11412-00-00	Stand - Footrest	2
262-21399-00-00	Cap, Tool Box	Stand - Footrest	2
1L9-81800-60-00	Starting Motor Assembly	Starting Motor	1
371-81845-20-00	Plate	Starting Motor	1
371-81844-20-00	Gasket	Starting Motor	1
371-81809-20-00	Washer, Kit	Starting Motor	1
1L9-81850-20-00	Armature Assembly	Starting Motor	1
1L9-81810-60-00	Stator Assembly	Starting Motor	1
1L9-81840-60-00	Brush Holder Assembly	Starting Motor	1
1L9-81811-60-00	Brush (+)	Starting Motor	1
1L9-81812-60-00	Brush (-)	Starting Motor	1
1L9-81813-20-00	Spring, Brush	Starting Motor	2
98501-03008-00	Screw, Pan Head With Washer (97602-03108)	Starting Motor	2
92901-03100-00	Washer, Spring (92901-03100)	Starting Motor	2
371-81847-20-00	O-Ring	Starting Motor	1
371-81826-20-00	Bolt (4x7-8l826-60)	Starting Motor	2
1L9-81847-60-00	O-Ring	Starting Motor	1
1L9-15518-60-00	Sprocket, Starter (13t)	Starting Motor	1
97301-06060-00	Bolt	Starting Motor	1
97301-06055-00	Bolt, Hexagon 005001~ M7-021	Starting Motor	1
1L9-15519-00-00	Sprocket, Starter 2	Starting Motor Unit	1
94552-19058-00	Chain, Starter (did219h2 58l)	Starting Motor Unit	1
1L9-15591-00-00	Guide, Starter Chain	Starting Motor Unit	1
1L9-15592-01-00	Guide, Starter Sprocket	Starting Motor Unit	1
97301-06014-00	Bolt, Hexagon (97301-06015) Se 114241~	Starting Motor Unit	1
341-15580-05-00	Starter Clutch Outer Assembly	Starting Motor Unit	1
93615-12088-00	Pin, Dowel (15-15)	Starting Motor Unit	3
341-15583-04-00	Cap, Starter Clutch Spring	Starting Motor Unit	3
90501-03298-00	Spring, Starter Clutch Roller (341-15584-03)	Starting Motor Unit	3
91310-08015-00	Bolt, Hexagon Socket Head	Starting Motor Unit	3
93605-09095-00	Pin, Dowel (4.5-9.3)	Starting Motor Unit	2
1L9-15436-00-00	Cover, Starting Motor	Starting Motor Unit	1
1L9-15446-00-00	Gasket, Starting Motor Cover	Starting Motor Unit	1
90105-06069-00	Bolt, Washer Based Head Hexagon	Starting Motor Unit	2
1L9-15589-00-00	Plate, Starter Clutch Cover	Starting Motor Unit	1
164-23462-00-00	Seal, Steering (usa)	Steering	1
156-23411-00-00	Race, Ball 1 032509	Steering	1
93501-04011-00	Ball (1/4 Inch) (93501-04004)	Steering	19
156-23412-00-00	Race, Ball 2 032509	Steering	1
183-23412-00-00	Race, Ball (2)	Steering	1

93501-04011-00	Ball (1/4 Inch) (93501-04004)	Steering	19
183-23411-00-00	Race, Ball (1)	Steering	1
136-23415-00-00	Cover, Ball Race	Steering	1
90179-25033-00	Nut, Steering Fitting (137-23454-00)	Steering	1
1L9-23435-00-98	Crown, Handle Low Gloss Black	Steering	1
90105-14102-00	Bolt, Round Hexagon (90106-14017)	Steering	1
256-23434-01-00	Rubber, Bushing 017354~	Steering	4
90209-12151-00	Washer, Special Shape	Steering	2
1E6-23442-00-00	Holder, Handle Lower (3r4-23442-00-98) Low Gloss Black	Steering	2
1E6-23441-10-98	Holder, Handle Upper Lgb - Color Info (lgb:low Gloss Black:0098)	Steering	2
90105-08091-00	Bolt, Washer Based Head Hexagon	Steering	4
90201-10149-00	Washer, Special (256-23444-00) 017354~ Pn320	Steering	2
92903-10100-00	Washer, Spring Use With Crank (l.h.) 214-11412-00-00	Steering	2
95302-10700-00	Nut	Steering	2
90468-12006-00	Clip, Tension Bar (136-25375-00)	Steering	2
97303-08055-00	Bolt, Hexagon	Steering	2
90201-08083-00	Washer, Pedal Link (8.2-13-0.6) (156-27226-00)	Steering	4
92903-08100-00	Washer, Spring (92902-08100) (optional Parts)	Steering	2
95303-08800-00	Nut, Crown (98803-08700) Iso	Steering	2
2A2-84710-60-00	Tail Lamp Unit Assembly	Tail Lamp	1
2A2-84711-60-00	Base, Tail Lamp	Tail Lamp	1
256-84714-61-00	Bulb, Tail Lamp (12v-32/3cp) (256-84714-60)	Tail Lamp	2
1A0-84723-60-00	Gasket, Tail Lamp	Tail Lamp	1
1A0-84721-60-00	Lens, Tail Lamp Canada	Tail Lamp	1
1A0-84724-60-00	Screw, Lens Fitting Canada	Tail Lamp	2
1A0-84712-60-00	Sheet, Base	Tail Lamp	1
2H7-84754-00-00	Washer, Special (437-84525-60) 02260~ Canada	Tail Lamp	2
1A0-84726-60-00	Bolt, Tail Lamp	Tail Lamp	2
2A2-84751-60-33	Bracket, License Yamaha Black	Tail Lamp	1
2A2-84753-01-00	Damper	Tail Lamp	1
90109-06465-00	Screw, Lever Fitting (341-83925-00)	Tail Lamp	2
90109-06489-00	Bolt, Special	Tail Lamp	2
92903-08200-00	Washer, Plain (92901-08200) Optional Parts	Tail Lamp	4
92903-06100-00	Washer, Spring Use With 214-15121-01-00 To 291-15121-00-00 Crankcase	Tail Lamp	4
95301-06600-00	Nut, Hexagon 250 Frame #200815- 400 Frame #008894-	Tail Lamp	4
2A2-84717-20-00	Cord, Tail Lamp	Tail Lamp	1
1L9-17401-00-00	Main Axle Assembly (14t)	Transmission	1
1L9-17141-00-00	Gear, 4th Pinion (24t)	Transmission	1
90201-25287-00	Washer, Plate (256-17154-00-10) 1204949-	Transmission	1
93440-25008-00	Circlip (250 Special) (93440-25019)	Transmission	3
1L9-17131-00-00	Gear, 3rd Pinion (21t)	Transmission	1
90209-21105-00	Washer, Gear Hold 1 (328-17216-00) Alternate Parts	Transmission	2

1L9-17161-00-00	Gear, 6th Pinion (30t)	Transmission	1
1A1-17121-00-00	Gear, 2nd Pinion (18t) (360-17121-00)	Transmission	1
90201-20266-00	Washer, Gear Hold (20-25-1) (132-17216-00-00)	Transmission	2
1L9-17151-00-00	Gear, 5th Pinion (26t)	Transmission	1
93410-20009-00	Circlip (21.2-29-2)	Transmission	1
93311-22027-00	Bearing (20-30-15) (93311-22005)	Transmission	1
93450-32042-00	Circlip, Inner	Transmission	1
168-17428-01-03	Shim, Drive Axle (25-34-0-3) Canada Only Ur	Transmission	0
168-17428-01-05	Shim, Drive Axle (25-36-1.5) (168-17428-00) Used On (168-17421-00), Transmission	Transmission	1
93305-20502-00	Bearing (93305-20508-00)	Transmission	1
93440-52009-00	Circlip (520 Special)	Transmission	1
1L9-17420-00-00	Drive Axle Assembly (25t)	Transmission	1
1L9-17221-00-00	Gear, 2nd Wheel (32t)	Transmission	1
90209-21105-00	Washer, Gear Hold 1 (328-17216-00) Alternate Parts	Transmission	3
93440-25008-00	Circlip (250 Special) (93440-25019)	Transmission	3
1L9-17261-00-00	Gear, 6th Wheel (26t)	Transmission	1
2A2-17231-00-00	Gear, 3rd Wheel Engine 0052015	Transmission	1
2A2-17241-00-00	Gear, 4th Wheel Engine 052015	Transmission	1
1L9-17210-00-00	Gear, 1st Wheel Assembly (35t)	Transmission	1
90201-20266-00	Washer, Gear Hold (20-25-1) (132-17216-00-00)	Transmission	1
93410-20009-00	Circlip (21.2-29-2)	Transmission	1
93311-42032-00	Bearing (20-33-1.5) (93311-42006)	Transmission	1
278-17425-00-00	Circlip 2 (u49)	Transmission	1
168-17428-01-03	Shim, Drive Axle (25-34-0-3) Canada Only Ur	Transmission	0
168-17428-01-05	Shim, Drive Axle (25-36-1.5) (168-17428-00) Used On (168-17421-00), Transmission	Transmission	1
93306-30506-00	Bearing (b6305n Special) (93306-30504)	Transmission	1
278-17424-00-00	Circlip	Transmission	1
93102-35109-00	Oil Seal (sd-35-62-6) (93102-35054)	Transmission	1
90387-25192-00	Collar, Distance (25.0-35.0-17.5) (169-17462-00)	Transmission	1
1A1-17461-60-00	Sprocket, Drive (16t) U. R.	Transmission	1
90215-21121-00	Washer, Lock (usa)	Transmission	1
90179-18020-00	Nut, Lock (152-17463-00)	Transmission	1
1L9-12111-02-00	Valve, Intake	Valve - Rocker Arm	2
1L9-12121-02-00	Valve, Exhaust	Valve - Rocker Arm	2
1L9-12116-00-00	Seat, Valve Spring	Valve - Rocker Arm	4
1L9-12114-00-00	Spring, Valve Outer	Valve - Rocker Arm	4
1L9-12113-00-00	Spring, Valve Inner	Valve - Rocker Arm	4
1L9-12119-00-00	Seal, Valve Stem Oil	Valve - Rocker Arm	4
1L9-12117-00-00	Retainer, Valve Spring	Valve - Rocker Arm	4
1J7-12118-00-00	Lock, Valve Spring Retainer	Valve - Rocker Arm	8
1L9-12151-00-00	Arm, Valve Rocker	Valve - Rocker Arm	4
1L9-12159-01-00	Screw, Valve Adjusting (1L9-12159-00)	Valve - Rocker Arm	4

90170-06128-00	Nut, Hexagon (371-12158-00)	Valve - Rocker Arm	4
1L9-12156-00-00	Shaft, Rocker Arm	Valve - Rocker Arm	4
90430-16142-00	Gasket, Rocker Plug	Valve - Rocker Arm	2
1L9-11177-00-00	Plug, Rocker	Valve - Rocker Arm	2
1L9-11197-00-00	Plug, Blind	Valve - Rocker Arm	2
93210-07242-00	O-Ring, Rocker Plug	Valve - Rocker Arm	2