

Model **XS400SG**
Year **1980**
Displace **400**
Description **XS400S Heritage**
Type **Street**
Code **3F9**

4R4-81600-50-00	Ac Generator Assembly (1I9-81600-50)	Ac Generator	1
3F9-81610-50-00	Stator Assembly	Ac Generator	1
3F9-81650-50-00	Rotor Assembly	Ac Generator	1
4R4-81660-50-00	Ac Generator Assembly (1I9-81660-50)	Ac Generator	1
90101-10105-00	Bolt, Hexagon (341-18652-00)	Ac Generator	1
92903-10100-00	Washer, Spring Use With Crank (l.h.) 214-11412-00-00	Ac Generator	1
90201-10508-00	Washer, Plate (10.1-24-5) (341-81663-01)	Ac Generator	1
91316-06014-00	Bolt, Hexagon Socket Head	Ac Generator	3
91316-06030-00	Bolt, Hexagon Socket Head	Ac Generator	3
1M0-12171-00-00	Camshaft 1	Camshaft - Chain	1
1L9-12176-00-00	Sprocket, Cam Chain (34t)	Camshaft - Chain	1
93603-07073-00	Locating Pin, Governor M5-016	Camshaft - Chain	1
90105-07087-00	Bolt, Washer Based Head Hexagon P07-11I	Camshaft - Chain	2
94500-02092-00	Chain, Camshaft (bf05m 92I) (usa)	Camshaft - Chain	1
94600-02001-00	Joint, Chain (bf05m) Tsuba Kimoto	Camshaft - Chain	1
1L9-12231-00-00	Guide, Stopper 1	Camshaft - Chain	1
1L9-12241-02-00	Guide, Stopper 2	Camshaft - Chain	1
1L9-12210-02-00	Tensioner Assembly, Cam Chain (1I9-12210-01-00)	Camshaft - Chain	1
95801-06016-00	Bolt, Flange	Camshaft - Chain	2
3F9-14900-00-00	Carburetor Assembly	Carburetor	1
3F9-14902-00-00	Carburetor Assembly 2	Carburetor	1
3F9-14901-00-00	Carburetor Assembly 1	Carburetor	1
1J7-14994-00-00	Net, Filter (usa)	Carburetor	2
584-14992-00-00	Rod, Push Se114241~	Carburetor	1
584-14934-00-00	Spring, Adjusting Se114241~	Carburetor	1
256-14937-00-00	Clip Pn343	Carburetor	1
256-14944-32-00	Jet, Main (#155.0) (256-14944-31)	Carburetor	2
3F7-14988-00-00	Pipe, Starter Connecting	Carburetor	1
1L9-14166-00-00	Bolt, Banjo	Carburetor	1
98503-05015-00	Screw, Pan Head Oil Pump Assembly Refer To M8-0150	Carburetor	8
92903-05100-00	Washer, Spring (92901-05100) Alternate Parts	Carburetor	8
1A8-14991-00-00	Screw, Plug Se114241~	Carburetor	2
1L9-14952-00-00	Washer, Drain Bolt	Carburetor	4
3F7-14171-00-00	Plunger, Starter	Carburetor	2
3F7-14173-00-00	Cover, Plunger Cap	Carburetor	2
3F7-14174-00-00	Cap, Plunger	Carburetor	2
3F7-14135-00-00	Spring, Plunger	Carburetor	2
98302-05006-00	Screw, Cylinder Head	Carburetor	2
97801-05006-00	Plug, Drain (256-24543-00)	Carburetor	8
3F7-14133-00-00	Spring, Throttle Stop	Carburetor	1
3F7-14922-00-00	Screw, Throttle Stop	Carburetor	1
452-14116-09-00	Needle	Carburetor	2
8F2-14147-00-00	O-Ring (8e2-14147-00)	Carburetor	2
3L1-14190-20-00	Needle Valve Assembly	Carburetor	2
537-14186-00-00	Pin, Float (usa)	Carburetor	2
2H0-14146-00-00	Plate, Valve Seat	Carburetor	2

98501-04005-00	Screw, Pan Head Used On 168-81200-22, Generator	Carburetor	2
3F7-14981-07-00	Body, Float Chamber	Carburetor	2
3F7-14985-00-00	Float	Carburetor	2
620-14231-27-A0	Jet, Main (#135.0)	Carburetor	2
137-14153-00-00	Washer, Main Jet (usa)	Carburetor	2
2A2-14941-92-00	Nozzle, Main	Carburetor	2
3F7-14991-00-00	Bracket (3f7-14995-00)	Carburetor	2
256-14142-42-A0	Jet, Pilot (#42.5)	Carburetor	2
3F7-14984-00-00	Gasket, Float Chamber	Carburetor	2
3F7-14940-01-00	Diaphragm Assembly	Carburetor	2
3F7-14918-00-00	Ring	Carburetor	2
256-14919-00-00	Clip Se114241~	Carburetor	2
3F7-14952-00-00	Washer	Carburetor	2
3F7-14589-00-00	Spring	Carburetor	2
3F7-14936-00-00	Seat, Spring	Carburetor	2
97602-03108-00	Screw, Round Head (98401-03008)	Carburetor	4
3F7-14933-00-00	Spring, Diaphragm	Carburetor	2
3F7-14958-01-00	Cover, Diaphragm For #2 & 4	Carburetor	2
1L9-14987-00-00	Hose	Carburetor	1
97801-06014-00	Screw, Pan Head	Carburetor	4
1L9-14146-00-00	Plate, Lower	Carburetor	1
3F7-14122-00-00	Screw, Throttle	Carburetor	1
3F7-14934-00-00	Spring, Throttle Stop	Carburetor	1
3F7-14995-00-00	Bracket	Carburetor	1
97801-05008-00	Screw, Pan Head (97804-05005)	Carburetor	4
93501-08001-00	Ball (1/8 Inch)	Carburetor	2
583-14589-00-00	Spring	Carburetor	2
2F3-14991-00-00	Screw, Plug (2a2-14991-00)	Carburetor	2
3F7-14905-00-00	Lever, Starter	Carburetor	2
2A2-14977-00-00	Shaft, Starter Lever	Carburetor	1
3F9-14118-00-00	Plug, Blind (3a3-14118-00)	Carburetor	2
1L9-16301-00-00	Clutch Assembly	Clutch	1
1L9-16150-01-00	Primary Driven Gear Comp. (78t)	Clutch	1
90201-25291-00	Washer, Plate (25.2-39-1.0) (371-11558-00)	Clutch	1
1L9-16371-00-00	Boss, Clutch	Clutch	1
1L9-16351-00-00	Plate, Pressure 1	Clutch	1
168-16325-00-00	Plate, Clutch 2 (t1.6) (usa)	Clutch	6
383-16321-00-00	Plate, Friction	Clutch	7
90501-26148-00	Spring, Clutch (256-16333-00) 001080~	Clutch	4
90159-06010-00	Screw, Cross Recess Hexagon	Clutch	4
1L9-16111-00-00	Gear, Primary Drive (24t)	Clutch	1
90105-10085-00	Bolt, Washer Based Head Hexagon Pa10-25l	Clutch	1
1L9-16356-00-00	Rod, Push 1	Clutch	1
371-16357-02-00	Rod, Push 2	Clutch	1
93505-16006-00	Ball, Steel (5/16 Inch)	Clutch	1
93102-09245-00	Oil Seal (sd-8.8-22-7.5) (93102-09151)	Clutch	1
1L9-16340-00-00	Push Lever Assembly	Clutch	1
371-16396-00-00	Housing, Push Screw (256-16396-01)	Clutch	1
214-16389-00-00	Joint, Pin M5-040	Clutch	1
90240-06005-00	Pin, With Hole (214-16379-00)	Clutch	1
91401-10010-00	Pin, Cotter (91402-10006)	Clutch	1
214-16347-01-00	Seal, Dust 001125~	Clutch	1
98503-05012-00	Screw, Pan Head 010651 -Xs750d M7-022 100101 -Xs750-2d	Clutch	2
90113-08021-00	Screw, Adjusting (256-16343-01) 001125~	Clutch	1
90179-08179-00	Nut, Adjusting (214-16344-00)	Clutch	1
90506-10023-00	Spring, Return (168-16345-00) 001125~	Clutch	1
93410-24042-00	Circlip (s-24)	Clutch	1
168-17428-01-03	Shim, Drive Axle (25-34-0-3) Canada Only Ur	Clutch	1
168-17428-01-05	Shim, Drive Axle (25-36-1.5) (168-17428-00) Used On (168-17421-00), Transmission	Clutch	1

1L9-15100-01-00	Crankcase Assembly	Crankcase	1
91810-03014-00	Pin, Dowel (10-8.5-14)	Crankcase	2
1L9-15412-00-00	Plate, Oil Guide	Crankcase	1
98501-05010-00	Screw, Pan Head (98503-05008) Used On 235-15411-00	Crankcase	2
90387-16547-00	Collar (16.5-18-10)	Crankcase	1
93210-18322-00	Cylinder Stud O-Rings Replace When Performing Top End Repairs	Crankcase	1
91830-24016-00	Pin, Dowel (10.5-14-16) (91800-16016)	Crankcase	2
90465-10092-00	Clamp	Crankcase	1
1L9-15138-01-00	Nozzle (119-15138-00)	Crankcase	1
90465-10110-00	Clamp	Crankcase	1
90105-06069-00	Bolt, Washer Based Head Hexagon	Crankcase	1
91810-03014-00	Pin, Dowel (10-8.5-14)	Crankcase	6
90105-06073-00	Bolt, Washer Based Head Hexagon M6-45l	Crankcase	5
90105-06074-00	Bolt, Washer Based Head Hexagon M6-50l	Crankcase	6
90105-06076-00	Bolt, Washer Based Head Hexagon M6-80l	Crankcase	1
90105-06077-00	Bolt, Washer Based Head Hexagon M6-105l	Crankcase	2
90105-08081-00	Bolt, Washer Based Head Hexagon M8-80l	Crankcase	1
90105-08082-00	Bolt, Washer Based Head Hexagon M8-110l	Crankcase	2
90105-08084-00	Bolt, Washer Based Head Hexagon M8-150l	Crankcase	4
90340-14034-00	Plug, Straight Screw (431-15351-00)	Crankcase	1
90430-14042-00	Gasket (14.1-21-1.0) (341-15396-00)	Crankcase	1
1L9-15123-00-00	Plate, Baffle 1	Crankcase	1
1L9-15124-00-00	Plate, Baffle 2	Crankcase	1
1L9-15122-00-00	Bar, Baffle Plate Fixed	Crankcase	1
90340-22047-00	Plug, Straight Screw	Crankcase	1
90430-22144-00	Gasket Use Set For Interchange	Crankcase	1
1L9-11108-00-00	Breather Cover Assembly	Crankcase	1
1L9-11169-00-00	Gasket, Breather Cover	Crankcase	1
90105-06071-00	Bolt, Washer Based Head Hexagon	Crankcase	4
2L0-11166-00-00	Pipe, Breather 1	Crankcase	1
90465-08111-00	Clamp	Crankcase	1
1L9-15411-10-00	Cover, Crankcase 1	Crankcase Cover	1
1L9-15461-00-00	Gasket, Crankcase Cover Left	Crankcase Cover	1
91316-06030-00	Bolt, Hexagon Socket Head	Crankcase Cover	5
91316-06040-00	Bolt, Hexagon Socket Head 1	Crankcase Cover	3
1L9-15415-01-00	Cover, Generator 1	Crankcase Cover	1
1L9-15455-01-00	Gasket, Carburetor Cover 1	Crankcase Cover	1
91316-05015-00	Bolt, Hexagon Socket Head	Crankcase Cover	4
1L9-15421-11-00	Cover, Crankcase Left 2	Crankcase Cover	1
91316-06065-00	Bolt, Hexagon Socket Head M6-65l	Crankcase Cover	4
91316-06040-00	Bolt, Hexagon Socket Head 1	Crankcase Cover	1
1L9-15441-00-00	Holder, Clutch Wire 1	Crankcase Cover	1
1L9-15417-00-00	Cover, Cap 1	Crankcase Cover	1
3F9-15431-11-00	Cover, Crankcase 3 (3f9-15431-10)	Crankcase Cover	1
3Y1-15361-00-00	Gauge, Level	Crankcase Cover	1
1L9-15451-00-00	Gasket, Crankcase Cover Right 1	Crankcase Cover	1
91316-06030-00	Bolt, Hexagon Socket Head	Crankcase Cover	3
91316-06040-00	Bolt, Hexagon Socket Head 1	Crankcase Cover	11
1L9-15362-00-00	Plug, Oil Level 1	Crankcase Cover	1
93210-27194-00	O-Ring (2.5-27.0)	Crankcase Cover	1
2A2-11411-00-00	Crankshaft	Crankshaft - Piston	1
90280-05015-00	Key, Woodruff	Crankshaft - Piston	1
90280-04005-00	Key, Woodruff (341-11545-00) Alternate Parts	Crankshaft - Piston	1
1L9-11416-00-00	Plane Bearing, Crankshaft 1 Ur Blue	Crankshaft - Piston	6
1L9-11416-10-00	Plane Bearing, Crankshaft 1 U. R. Black	Crankshaft - Piston	6
1L9-11416-20-00	Plane Bearing, Crankshaft 1 U. R. Brown	Crankshaft - Piston	6
1L9-11416-30-00	Plane Bearing, Crankshaft 1 U. R. Green	Crankshaft - Piston	6
2A2-11633-00-00	Pin, Piston	Crankshaft - Piston	2
2L0-11631-00-YO	Piston (size B Std) U. R.	Crankshaft - Piston	2

2L0-11635-00-00	Piston (69.25mm 1st O/s) Alternate Part	Crankshaft - Piston	2
2L0-11636-00-00	Piston (69.50mm 2nd O/s) Alternate Part	Crankshaft - Piston	2
2L0-11637-00-00	Piston (69.75mm 3rd O/s) Alternate Part	Crankshaft - Piston	2
2L0-11638-00-00	Piston (70.00mm 4th O/s) Alternate Part	Crankshaft - Piston	2
2A2-11610-00-00	Piston Ring Set (std)	Crankshaft - Piston	2
2A2-11610-10-00	Piston Ring Set (1st O/s) Alternate Parts	Crankshaft - Piston	2
2A2-11610-20-00	Piston Ring Set (2nd O/s) Alternate Parts	Crankshaft - Piston	2
2A2-11610-30-00	Piston Ring Set (3rd O/s) Alternate Parts	Crankshaft - Piston	2
2A2-11610-40-00	Piston Ring Set (4th O/s) Alternate Parts	Crankshaft - Piston	2
93450-17044-00	Circlip (usa)	Crankshaft - Piston	4
1L9-Y1165-00-00	Connecting Rod Assembly (1I9-11650-00)	Crankshaft - Piston	2
371-11654-01-00	Bolt, Connecting Rod	Crankshaft - Piston	2
90170-08129-00	Nut, Hexagon (371-11655-00)	Crankshaft - Piston	2
1L9-11656-00-00	Plane Bearing, Connecting Rod Ur Blue	Crankshaft - Piston	4
1L9-11656-10-00	Plane Bearing, Connecting Rod U. R. Black	Crankshaft - Piston	4
1L9-11656-20-00	Plane Bearing, Connecting Rod U. R. Brown	Crankshaft - Piston	4
1L9-11656-30-00	Plane Bearing, Connecting Rod U. R. Green	Crankshaft - Piston	4
2A2-11181-00-00	Gasket, Cylinder Head 1	Cylinder	1
1L9-11162-30-00	Absorber 2	Cylinder	4
1L9-11361-00-00	Bolt, Cylinder Holding 1	Cylinder	4
1L9-11362-00-00	Bolt, Cylinder Holding 2	Cylinder	4
2L0-11310-00-00	Cylinder (2I0-11311-00)	Cylinder	1
93210-74316-00	O-Ring, Cylinder Base	Cylinder	2
2A2-11351-00-00	Gasket, Cylinder Base	Cylinder	1
2L0-11101-00-00	Cylinder Head Assembly	Cylinder Head	1
1L9-11133-10-00	Guide, Valve Intake (1st O/s) Alternate Part	Cylinder Head	4
93440-12052-00	Circlip (120 Special)	Cylinder Head	4
91810-03014-00	Pin, Dowel (10-8.5-14)	Cylinder Head	2
1L9-11162-10-00	Absorber 1	Cylinder Head	2
1L9-11171-00-00	Nut, Cylinder Holding	Cylinder Head	8
90201-10128-00	Washer, Plate (10.5-20-2) (341-83909-00)	Cylinder Head	8
90105-06070-00	Bolt, Washer Based Head Hexagon M6-25l	Cylinder Head	2
90116-08046-00	Bolt, Stud (823-13558-00)	Cylinder Head	4
90105-06073-00	Bolt, Washer Based Head Hexagon M6-45l	Cylinder Head	4
90105-08078-00	Bolt, Washer Based Head Hexagon M8-40l	Cylinder Head	1
90105-08079-00	Bolt, Washer Based Head Hexagon M8-50l	Cylinder Head	5
90105-08080-00	Bolt, Washer Based Head Hexagon M8-60l	Cylinder Head	2
90105-06075-00	Bolt, Washer Based Head Hexagon M6-60l	Cylinder Head	2
1H2-11186-00-00	Plug, Viewer 102260~ Canada	Cylinder Head	4
93210-32172-00	O-Ring (2.4-31.5) 102260~ Canada	Cylinder Head	4
1L9-11177-01-00	Plug, Rocker	Cylinder Head	2
90430-16142-00	Gasket, Rocker Plug	Cylinder Head	2
93210-07242-00	O-Ring, Rocker Plug	Cylinder Head	2
1L9-11197-00-00	Plug, Blind	Cylinder Head	2
3F9-11157-00-00	Cover, Breaker 1	Cylinder Head	1
90334-11035-00	Plug, Straight	Cylinder Head	1
98501-05035-00	Screw, Pan Head Iso	Cylinder Head	1
98501-05016-00	Screw, Pan Head (98506-05016)	Cylinder Head	1
93102-23190-00	Oil Seal (sd-23-35-5) (93102-23152)	Cylinder Head	1
94701-00117-00	Plug, Spark (ngk Bp-7es) U. R.	Cylinder Head	2
94701-00135-00	Plug, Spark (champion (n-7y) U. R.	Cylinder Head	2
91830-24016-00	Pin, Dowel (10.5-14-16) (91800-16016)	Cylinder Head	3
90430-14131-00	Gasket, Dowel Pin	Cylinder Head	1
90201-06630-00	Washer, Plate	Cylinder Head	2
2L0-81910-50-00	Voltage Regulator Assembly	Electrical	1
92503-06012-00	Screw, Pan Head Necessary If Horn Is Equipped	Electrical	2
92903-06100-00	Washer, Spring Use With 214-15121-01-00 To 291-15121-00-00 Crankcase	Electrical	2
366-82110-79-00	Battery Assembly (366-82110-60) 12n12a-4a-1	Electrical	1
LIT-82141-09-00	Label, Battery (118-82141-09) Exclusive For U.s.a.	Electrical	1

1L9-82122-00-00	Seat, Battery	Electrical	1
122-82131-00-00	Band, Battery (116-82131-00)	Electrical	1
371-82121-00-00	Pad, Battery (u49)	Electrical	4
90445-08348-00	Hose (5.0-580)	Electrical	1
2L0-82115-00-00	Wire, Plus Lead	Electrical	1
1L9-82119-00-00	Cover, Lead Wire	Electrical	1
1L9-82116-01-00	Wire, Minus Lead	Electrical	1
2L0-82171-00-00	Stay, Fuse Box	Electrical	1
98501-05016-00	Screw, Pan Head (98506-05016)	Electrical	1
92903-05100-00	Washer, Spring (92901-05100) Alternate Parts	Electrical	1
92901-05600-00	Washer, Plate Alternate Parts	Electrical	1
98501-05016-00	Screw, Pan Head (98506-05016)	Electrical	2
92903-05100-00	Washer, Spring (92901-05100) Alternate Parts	Electrical	2
92901-05600-00	Washer, Plate Alternate Parts	Electrical	2
2F3-82310-60-00	Ignition Coil Assembly	Electrical	2
3F9-82341-00-00	Cord, High Tension	Electrical	2
92903-06100-00	Washer, Spring Use With 214-15121-01-00 To 291-15121-00-00 Crankcase	Electrical	4
95301-06600-00	Nut, Hexagon 250 Frame #200815- 400 Frame #008894	Electrical	4
1L9-82370-00-00	Plug Cap Assembly U. R.	Electrical	2
3F9-82590-50-00	Wire Harness Assembly	Electrical	1
1A0-82161-00-00	Fuse (12v-20a) (148-82151-00)	Electrical	1
1A0-82151-00-00	Fuse (12v-10a)	Electrical	3
3H5-81980-00-00	Diode Assembly	Electrical	1
437-83936-00-00	Band, Switch Cord (optional Parts)	Electrical	1
437-83936-10-00	Band (803-82591-00)	Electrical	2
341-26397-01-00	Band California Model	Electrical	1
1J7-81940-10-00	Starter Switch Assembly U. R.	Electrical	1
95301-06700-00	Nut, Hexagon Optional Parts	Electrical	2
92903-06100-00	Washer, Spring Use With 214-15121-01-00 To 291-15121-00-00 Crankcase	Electrical	2
1L9-81916-00-00	Cover, Terminal	Electrical	1
1L9-81970-60-00	Rectifier Assembly (1a0-81976-60)	Electrical	1
92503-06020-00	Screw, Pan Head (92501-06020)	Electrical	1
92903-06100-00	Washer, Spring Use With 214-15121-01-00 To 291-15121-00-00 Crankcase	Electrical	1
3H5-81950-00-00	Headlight Relay Assembly	Electrical	1
1L9-82540-00-00	Neutral Switch Assembly (278-82540-01)	Electrical	1
93210-29196-00	O-Ring (2.4-29.4)	Electrical	1
98701-05012-00	Screw, Flat Head	Electrical	3
341-82504-02-00	Oil Pressure Switch Assembly (11h-82504-00)	Electrical	1
1L9-82530-00-00	Stop Switch Assembly	Electrical	1
1L9-82539-01-00	Stay, Stop Switch	Electrical	1
2L0-82508-50-00	Main Switch Steering Lock Assembly	Electrical	1
97301-06016-00	Bolt, Hexagon (97301-06015) Se ~11424C	Electrical	2
92901-06600-00	Washer, Plate Alternate Parts (u.s.a. Only)	Electrical	2
4R4-82305-10-00	Ignitor Unit Assembly (3f9-82305-10)	Electrical	1
92503-06020-00	Screw, Pan Head (92501-06020)	Electrical	3
92903-06100-00	Washer, Spring Use With 214-15121-01-00 To 291-15121-00-00 Crankcase	Electrical	3
92901-06600-00	Washer, Plate Alternate Parts (u.s.a. Only)	Electrical	3
2L0-83371-20-00	Horn	Electrical	1
97301-06012-00	Bolt, Hexagon (91201-06012)	Electrical	2
92903-06100-00	Washer, Spring Use With 214-15121-01-00 To 291-15121-00-00 Crankcase	Electrical	2
92901-06600-00	Washer, Plate Alternate Parts (u.s.a. Only)	Electrical	2
3F9-14710-02-00	Muffler Assembly 1 (3f9-14710-01)	Exhaust	1
91316-08025-00	Bolt, Hexagon Socket Head Cap (90110-08008)	Exhaust	1
3F9-14720-02-00	Muffler Assembly 2 (3f9-14720-01)	Exhaust	1
1L9-14613-00-00	Gasket, Exhaust Pipe	Exhaust	2
1J7-14614-00-00	Flange, Exhaust Pipe	Exhaust	4
95301-08600-00	Nut (98801-08100) Optional Parts	Exhaust	4
2G2-14714-00-00	Gasket, Muffler Joint	Exhaust	1
3F9-14771-00-00	Stay, Muffler 1	Exhaust	2

92903-08100-00	Washer, Spring (92902-08100) (optional Parts)	Exhaust	4
95301-08600-00	Nut (98801-08100) Optional Parts	Exhaust	4
278-27114-00-00	Stopper, Main Stand Alternate Parts (usa Only)	Exhaust	1
341-83310-72-93	Front Flasher Light Assembly 1 Chrome Plated	Flasher Light	2
341-83312-70-00	Lens, Flasher (canada Amber)	Flasher Light	1
341-83313-70-00	Gasket, Flasher Lens	Flasher Light	1
256-83311-70-00	Bulb, Flasher (12v-25w) (183-83311-70)	Flasher Light	1
341-83333-70-00	Screw, Lens Fitting Screw	Flasher Light	2
341-83367-09-00	Bolt, Stud (134-83367-00)	Flasher Light	1
341-83316-01-00	Collar, Flasher Front	Flasher Light	2
341-83321-01-00	Damper, Flasher 1	Flasher Light	2
90209-08098-00	Washer, Special 2 (341-83348-00)	Flasher Light	2
371-82519-00-00	Wire, Earth Front (120l)	Flasher Light	2
92903-08100-00	Washer, Spring (92902-08100) (optional Parts)	Flasher Light	2
95301-08600-00	Nut (98801-08100) Optional Parts	Flasher Light	2
2L0-83340-E0-93	Rear Flasher Light Assembly Chrome Plated	Flasher Light	2
1A0-83312-K0-00	Lens, Flasher	Flasher Light	1
341-83313-70-00	Gasket, Flasher Lens	Flasher Light	1
256-83311-70-00	Bulb, Flasher (12v-25w) (183-83311-70)	Flasher Light	1
341-83333-70-00	Screw, Lens Fitting Screw	Flasher Light	2
360-83367-09-00	Bolt, Stud (360-83367-00)	Flasher Light	1
1U4-83316-00-00	Collar, Flasher Right	Flasher Light	1
1U4-83326-00-00	Collar, Flasher Left	Flasher Light	1
1U4-83321-00-00	Damper, Flasher 1	Flasher Light	2
90209-08098-00	Washer, Special 2 (341-83348-00)	Flasher Light	2
92903-08100-00	Washer, Spring (92902-08100) (optional Parts)	Flasher Light	2
95301-08600-00	Nut (98801-08100) Optional Parts	Flasher Light	2
2L0-83354-00-00	Wire, Earth Lead 1	Flasher Light	1
2L0-83364-00-00	Wire, Earth Lead 2	Flasher Light	1
1A0-83350-70-00	Flasher Relay Assembly Round Body	Flasher Light	1
1A0-83395-03-00	Flasher Cancelling Unit Assembly (1a0-83395-02)	Flasher Light	1
3F9-21110-00-33	Frame Comp Yamaha Black	Frame	1
1L9-21315-00-00	Stay, Engine Rear Upper Right	Frame	1
2A2-21315-00-00	Stay, Engine Rear Upper Left	Frame	1
95821-08018-00	Bolt, Flange (95822-08018)	Frame	4
1L9-21316-01-00	Stay, Engine Left	Frame	1
1L9-21317-01-00	Stay, Engine Right	Frame	1
1A1-15316-00-00	Damper, Engine Mount 1	Frame	2
95821-08070-00	Bolt, Flange	Frame	2
95301-08600-00	Nut (98801-08100) Optional Parts	Frame	2
92903-08100-00	Washer, Spring (92902-08100) (optional Parts)	Frame	6
95821-10145-00	Bolt, Flange	Frame	2
95821-10045-00	Bolt, Flange	Frame	2
90105-08120-00	Bolt, Engine Mounting Front (90105-08022)	Frame	1
90170-10159-00	Nut, Hexagon	Frame	4
95301-08600-00	Nut (98801-08100) Optional Parts	Frame	1
92903-10100-00	Washer, Spring Use With Crank (l.h.) 214-11412-00-00	Frame	4
92903-08100-00	Washer, Spring (92902-08100) (optional Parts)	Frame	1
1L9-25831-00-00	Disc, Rear Brake	Front Brake - Calipe	1
3H5-25834-00-00	Washer, Lock	Front Brake - Calipe	3
90101-08477-00	Bolt, Hexagon	Front Brake - Calipe	6
3F9-25810-02-00	Caliper Assembly (rh) (3f9-25810-01)	Front Brake - Calipe	1
3J6-W0045-01-00	Brake Pad Kit, Front (3j6-W0045-00-00)	Front Brake - Calipe	1
2G2-W0047-00-00	Caliper Seal Kit (2g2-W0047-02)	Front Brake - Calipe	1
1J3-W0048-00-00	Screw, Bleed With Cap (1j3-20000-30)	Front Brake - Calipe	1
2G2-25919-00-00	Pad, Spring, Caliper	Front Brake - Calipe	1
2V0-25849-00-00	Retainer, Caliper	Front Brake - Calipe	1
90201-08689-00	Washer, Plate	Front Brake - Calipe	1
2G2-W0044-00-00	O-Ring Kit, Caliper	Front Brake - Calipe	1

2G2-25838-00-00	Sleeve, Caliper	Front Brake - Calipe	1
90201-09690-00	Washer (92901-09690)	Front Brake - Calipe	1
2G2-25821-00-00	Bolt, Swing	Front Brake - Calipe	1
2G2-25916-00-00	Cap, Swing Bolt	Front Brake - Calipe	1
90101-10308-00	Bolt (306-25818-00)	Front Brake - Calipe	2
92903-10100-00	Washer, Spring Use With Crank (l.h.) 214-11412-00-00	Front Brake - Calipe	2
92903-10200-00	Washer, Spring (92901-10200)	Front Brake - Calipe	2
2L0-21510-01-93	Front Fender Comp (2L0-21510-00-93) Chrome Plated	Front Fender - Rear	1
1A0-21518-00-00	Holder, Caable	Front Fender - Rear	1
90101-08253-00	Bolt, Hexagon	Front Fender - Rear	4
92903-08200-00	Washer, Plain (92901-08200) Optional Parts	Front Fender - Rear	4
3F9-21610-00-93	Rear Fender Comp Chrome Plated	Front Fender - Rear	1
90480-15061-00	Grommet 102260~ Canada	Front Fender - Rear	1
168-21638-00-00	Damper, Front	Front Fender - Rear	4
92901-12200-00	Washer, (92902-12200)	Front Fender - Rear	4
248-21635-00-00	Nut, Rear Fender	Front Fender - Rear	4
97306-08025-00	Bolt (97316-08025)	Front Fender - Rear	4
92906-08100-00	Washer, Spring Ca Only	Front Fender - Rear	4
92906-08600-00	Washer, Plate Ca Only	Front Fender - Rear	4
2L0-21268-00-00	Seal	Front Fender - Rear	1
3F9-24756-00-00	Cover, Tail	Front Fender - Rear	1
3F9-2472E-00-00	Support, Tool	Front Fender - Rear	2
90201-06552-00	Washer, Plate (6.5-20-1.6)	Front Fender - Rear	2
97301-06014-00	Bolt, Hexagon (97301-06015) Se 114241~	Front Fender - Rear	2
3F9-21620-00-00	Mud Guard Comp	Front Fender - Rear	1
90464-16025-00	Clamp	Front Fender - Rear	1
97306-06014-00	Bolt, Hexagon	Front Fender - Rear	2
92906-06100-00	Washer, Spring California Model Only	Front Fender - Rear	2
97301-06016-00	Bolt, Hexagon (97301-06015) Se ~114240	Front Fender - Rear	2
92903-06100-00	Washer, Spring Use With 214-15121-01-00 To 291-15121-00-00 Crankcase	Front Fender - Rear	2
90201-06059-00	Washer, Plate (838-77728-00)	Front Fender - Rear	4
3F9-21645-00-00	Stay, Rear	Front Fender - Rear	1
97311-08020-00	Bolt	Front Fender - Rear	2
92903-08200-00	Washer, Plain (92901-08200) Optional Parts	Front Fender - Rear	2
90201-100A1-00	Washer, Plate (90201-10141-00)	Front Fender - Rear	4
90176-10009-00	Nut, Crown Alternate Parts	Front Fender - Rear	2
1L9-28100-10-00	Tool Assembly	Front Fender - Rear	1
3F9-23101-00-00	Front Fork Assembly (2L0-23101-00)	Front Fork	1
1L9-23136-01-00	Tube, Outer Right	Front Fork	1
2L0-23126-00-00	Tube, Outer Left (1I9-23126-01)	Front Fork	1
1L9-23146-00-00	Washer, Oil Seal	Front Fork	2
1L9-23145-00-00	Oil Seal	Front Fork	2
1L9-23156-00-00	Clip, Oil Seal	Front Fork	2
90116-08260-00	Bolt, Stud (1e7-23182-00)	Front Fork	2
1E7-23167-00-00	Holder, Axle	Front Fork	1
92901-08600-00	Washer, Plate Alternate Parts (u.s.a. Only)	Front Fork	2
90185-08089-00	Nut, Self- Locking (90185-08054)	Front Fork	2
1E7-23181-00-00	Bolt, Hexagon Socket Head (2y4-23181-00)	Front Fork	2
1E7-23119-00-00	Plug, Drain With Gasket	Front Fork	2
1L9-23166-00-00	Spacer, Oil Lock	Front Fork	2
1L9-23170-02-00	Cylinder Comp, Front Fork (1I9-23170-01)	Front Fork	2
1E7-23151-00-00	Spring, Rebound	Front Fork	2
1E7-23157-00-00	Ring, Piston Front Fork	Front Fork	2
1L9-23144-00-00	Seal, Dust	Front Fork	2
2L0-23110-00-00	Inner Tube Comp 1	Front Fork	2
2L0-23141-00-00	Spring, Front Fork	Front Fork	2
1L9-23168-00-00	Cap, Front Fork	Front Fork	2
1L9-23183-00-00	Ring, Stopper	Front Fork	2
1L9-23114-00-00	O-Ring (2.8-19.4)	Front Fork	2

1L9-23111-00-00	Seat, Spring	Front Fork	2
2L0-23340-00-90	Under Bracket Comp (2I0-23340-00-33) Yamaha Black	Front Fork	1
92903-10100-00	Washer, Spring Use With Crank (I.h.) 214-11412-00-00	Front Fork	2
97323-10035-00	Bolt (97321-10035)	Front Fork	2
2L0-23122-00-93	Cover, Outer 1 Chrome Plated	Front Fork	1
2L0-23163-00-00	Gasket	Front Fork	4
2L0-23116-00-00	Guide, Cover Upper	Front Fork	2
2M0-23395-00-00	Emblem, Front	Front Fork	1
90202-04003-00	Damper, Emblem (174-28316-00)	Front Fork	2
90183-04005-00	Nut (116-28317-01) Candy Orange	Front Fork	2
3F9-23131-00-93	Cover, Upper 2 Chrome Plated	Front Fork	1
3F9-23121-00-93	Cover, Upper 1 Chrome Plated	Front Fork	1
2L0-23318-00-00	Holder, Cable 1	Front Fork	1
2N8-85111-00-00	Reflector, Front 1 (355-85111-00) Alternate Parts	Front Fork	2
92901-05200-00	Washer, Plain Alternate Prts	Front Fork	2
92903-05100-00	Washer, Spring (92901-05100) Alternate Parts	Front Fork	2
3G1-25850-00-00	Master Cylinder Assembly	Front Master Cylinder	1
535-W0041-60-00	Cylinder Kit, Master (535-20000-60) 1	Front Master Cylinder	1
1J3-25852-01-00	Reservoir Cap Assembly	Front Master Cylinder	1
98706-05030-00	Screw, Cap (98703-05030)	Front Master Cylinder	4
1J3-25855-01-00	Bushing, Diaphragm	Front Master Cylinder	1
1J3-25854-01-00	Diaphragm, Reservoir	Front Master Cylinder	1
1J3-25867-00-00	Bracket, Master (360-25867-01) Frosting Black	Front Master Cylinder	1
90338-09012-00	Plug, Blind (341-26329-00)	Front Master Cylinder	1
97326-06025-00	Bolt	Front Master Cylinder	2
92906-06100-00	Washer, Spring California Model Only	Front Master Cylinder	2
1T5-26372-00-00	Cover, Handle Lever 1, (rh)	Front Master Cylinder	1
3F9-25872-00-00	Hose, Brake 1	Front Master Cylinder	1
306-25862-00-00	Boot, Master Cylinder	Front Master Cylinder	1
90401-10034-00	Bolt, Union (90201-10118)	Front Master Cylinder	2
90201-10118-00	Washer, Oil Bolt (10.2-14-1.0) (306-25878-00)	Front Master Cylinder	4
2L0-25875-00-00	Holder, Brake Hose 1	Front Master Cylinder	1
97321-06012-00	Bolt (91201-06012)	Front Master Cylinder	1
92903-06100-00	Washer, Spring Use With 214-15121-01-00 To 291-15121-00-00 Crankcase	Front Master Cylinder	1
1L9-25876-00-00	Holder, Brake Hose 2	Front Master Cylinder	1
97301-06025-00	Bolt, Hexagon (97302-06025)	Front Master Cylinder	1
92903-06100-00	Washer, Spring Use With 214-15121-01-00 To 291-15121-00-00 Crankcase	Front Master Cylinder	1
3F9-25168-20-98	Cast Wheel, Front (3f9-25168-00-98) Low Gloss Black	Front Wheel	1
90560-15161-00	Spacer	Front Wheel	1
146-25115-00-00	Flange, Spacer 1 (148-25115-00)	Front Wheel	1
93306-30206-00	Bearing (b6302zz)	Front Wheel	2
93102-22014-00	Oil Seal (sd-22-42-7)	Front Wheel	1
341-25149-00-00	Clutch, Meter	Front Wheel	1
341-25846-00-00	Retainer, Clutch Meter	Front Wheel	1
93105-45017-00	Oil Seal (sdd-45-56-6)	Front Wheel	1
94130-18406-00	Tire (3.00-18) Yokohama	Front Wheel	1
93900-00001-00	Valve, Rim (16024 101) U. R. Bridgestone	Front Wheel	1
93900-00002-00	Valve, Rear (tubeless Tire) 166556~	Front Wheel	1
1A1-25399-00-00	Balancer, Wheel (10g) U. N.	Front Wheel	1
1A1-25398-01-00	Balancer, Wheel (1a1-25398-00) U.n. 20g	Front Wheel	1
2M0-25399-00-00	Balance, Wheel Un 30g Se 114241~	Front Wheel	1
1L9-25190-00-00	Gear Unit Assembly	Front Wheel	1
1L9-25181-00-00	Shaft, Wheel	Front Wheel	1
90171-14020-00	Nut, Wheel Shaft (214-25182-01)	Front Wheel	1
91401-30030-00	Pin, Cotter (91401-30022) Original	Front Wheel	1
92901-14200-00	Washer, Plain	Front Wheel	1
90387-15550-00	Collar	Front Wheel	1
401-25367-00-00	Cover, Hub Dust	Front Wheel	1
2L0-24110-00-2J	Fuel Tank Comp U. R. Black Red	Fuel Tank	1

2L0-24110-00-4H	Fuel Tank Comp U. R. Cardinal Red	Fuel Tank	1
90249-03123-00	Pin, Special Shape	Fuel Tank	1
93430-02001-00	Circlip (e-1.9)	Fuel Tank	1
1L9-24181-00-00	Damper, Locating Front 1	Fuel Tank	2
2L0-24182-00-00	Damper, Tank Locating 2	Fuel Tank	1
2L0-24183-00-00	Damper, Tank Locating 3	Fuel Tank	1
2L0-24500-02-00	Fuel Cock Assembly 1 (2L0-24500-01)	Fuel Tank	1
2G2-24524-00-00	Lever, Fuel Cock Left	Fuel Tank	1
2G2-24523-00-00	Gasket, Cock Body	Fuel Tank	1
2G2-24518-00-00	Washer, Wave	Fuel Tank	1
2G2-24525-00-00	Plate, Lever Fitting Left	Fuel Tank	1
98501-03008-00	Screw, Pan Head With Washer (97602-03108)	Fuel Tank	2
2L0-24551-00-00	Bolt, Joint	Fuel Tank	1
2L0-24514-00-00	Filter, Fuel Cock	Fuel Tank	1
2G2-24512-00-00	Gasket, Fuel Cock	Fuel Tank	1
2L0-24522-00-00	O-Ring	Fuel Tank	1
2G2-24534-00-00	Seal, Fuel Cock	Fuel Tank	1
90202-06010-00	Washer, Protector (6.2-12-1.5) (178-14766-00)	Fuel Tank	2
90149-06008-00	Bolt, Cock Connecting (366-24143-00) 4	Fuel Tank	2
90445-10133-00	Pipe, Fuel (6-135) (824-24315-00)	Fuel Tank	1
90445-09496-00	Hose (I310)	Fuel Tank	1
90467-09006-00	Clip California Model Only	Fuel Tank	2
90467-08003-00	Clip, Pipe (101-24356-00) Pn253	Fuel Tank	2
2L0-24602-00-00	Fuel Tank Cap Assembly	Fuel Tank	1
98501-05010-00	Screw, Pan Head (98503-05008) Used On 235-15411-00	Fuel Tank	1
92903-05100-00	Washer, Spring (92901-05100) Alternate Parts	Fuel Tank	1
3F9-24161-00-00	Emblem 1	Fuel Tank	1
3F9-24162-00-00	Emblem 2	Fuel Tank	1
90152-04006-00	Screw, Countersunk	Fuel Tank	4
97301-08018-00	Bolt, Hexagon 102260~ (canada Only)	Fuel Tank	1
92903-08100-00	Washer, Spring (92902-08100) (optional Parts)	Fuel Tank	1
90201-08114-00	Washer, Special (8.5-26-2.0) (156-24186-00)	Fuel Tank	1
2H7-83975-01-00	Switch, Handle 2 (2h7-83975-00-98) Low Gloss Black	Handle Switch - Lev	1
98501-05030-00	Screw , Lever Fitting (355-24535-00)	Handle Switch - Lev	1
98501-05040-00	Screw, Pan Head (98502-05040)	Handle Switch - Lev	1
3F9-83973-00-00	Switch, Handle 3	Handle Switch - Lev	1
98501-05030-00	Screw , Lever Fitting (355-24535-00)	Handle Switch - Lev	2
437-83936-00-00	Band, Switch Cord (optional Parts)	Handle Switch - Lev	4
341-82911-00-00	Holder, Lever Left Low Gloss Black	Handle Switch - Lev	1
2H7-83912-00-00	Lever, Left Low Gloss Black	Handle Switch - Lev	1
90109-06410-00	Bolt, Lever	Handle Switch - Lev	1
90201-08083-00	Washer, Pedal Link (8.2-13-0.6) (156-27226-00)	Handle Switch - Lev	1
95601-06100-00	Nut, U Optional Equipment	Handle Switch - Lev	1
97306-06022-00	Bolt	Handle Switch - Lev	1
92906-06100-00	Washer, Spring California Model Only	Handle Switch - Lev	1
2J2-83922-00-00	Lever, Right Low Gloss Black	Handle Switch - Lev	1
1A0-83980-30-00	Front Stop Switch Assembly 1	Handle Switch - Lev	1
90149-06131-00	Screw, Oval Head (90146-06008)	Handle Switch - Lev	1
90501-10312-00	Spring, Lever Return (306-83924-00)	Handle Switch - Lev	1
90170-06010-00	Nut, Adjusting (306-83917-00) Pn330	Handle Switch - Lev	1
90109-06465-00	Screw, Lever Fitting (341-83925-00)	Handle Switch - Lev	1
95601-06100-00	Nut, U Optional Equipment	Handle Switch - Lev	1
3F9-26110-00-00	Handle Comp (3f9-26111-00)	Handlebar - Cable	1
2H7-26241-00-00	Grip, Left	Handlebar - Cable	1
2H7-26240-00-00	Grip Assembly, Right	Handlebar - Cable	1
3F9-26311-01-00	Cable, Throttle 1 (3f9-26311-00-00)	Handlebar - Cable	1
584-26393-02-00	Heater Assembly Model Only Ur Cal. Only	Handlebar - Cable	1
3F9-26335-00-00	Cable, Clutch	Handlebar - Cable	1
1E6-26342-00-00	Cover, Clutch Lever	Handlebar - Cable	1

1E6-26372-00-00	Cover, Handle Lever Left	Handlebar - Cable	1
90123-08046-00	Bolt, Wire Adjusting (90123-08053) Alternate Parts	Handlebar - Cable	1
90179-08148-00	Nut, Wire Adjusting (168-26344-00)	Handlebar - Cable	1
341-26397-01-00	Band California Model	Handlebar - Cable	1
2G2-26290-10-00	Mirror Assembly Optional Parts	Handlebar - Cable	1
2G2-26290-00-00	Back Mirror Assembly, Right Optional Parts	Handlebar - Cable	1
1A0-84330-60-93	Body Assembly Chrome Plated	Headlight	1
498-84145-60-00	Collar Body Fitting 2	Headlight	2
498-84163-60-00	Damper, Head Lamp	Headlight	2
498-84164-60-00	Damper, Head Lamp	Headlight	2
1A0-84310-61-00	Head Lamp Unit Assembly	Headlight	1
1A0-84320-61-00	Lens Assembly	Headlight	1
371-84312-60-00	Socket Cord Assembly	Headlight	1
1A0-84395-60-00	Ring, Retaining	Headlight	1
1A0-84315-60-00	Rim, Head Lamp	Headlight	1
438-84194-60-00	Screw, Rim Fitting (2h0-84125-60-00)	Headlight	2
92903-05100-00	Washer, Spring (92901-05100) Alternate Parts	Headlight	2
90157-04001-00	Screw, Rim Adjuster (214-84131-61) Iso	Headlight	1
1A0-84332-60-00	Spring, Compression	Headlight	1
198-84334-60-00	Nut, Adjusting Alternate Parts	Headlight	1
507-84324-60-00	Spring, Reflector Set	Headlight	3
90152-05005-00	Screw, Rim Fitting Used On 168-84311-01-22 Head/taillight	Headlight	1
2A2-13586-00-00	Joint, Carburetor Left	Intake	1
2A2-13596-00-00	Joint, Carburetor Right	Intake	1
90460-51131-00	Clamp, Hose	Intake	2
1L9-13556-00-00	Gasket, Manifold	Intake	2
91316-06020-00	Bolt, Hexagon Socket Head (91318-06020)	Intake	4
1J7-13569-00-00	Plug, Blind	Intake	1
2A2-14411-00-00	Case, Air Cleaner 1	Intake	2
2A2-14421-00-00	Case, Air Cleaner 2	Intake	2
90480-50194-00	Grommet	Intake	2
1L9-14451-00-00	Element, Air Cleaner	Intake	2
98503-04014-00	Screw, Pan Head (98503-04015) Used On 168-14101-03/2-03 Or 211-14101-61/2-61	Intake	4
92901-04600-00	Washer, Spring (92901-04100-00)	Intake	4
90460-58124-00	Clamp, Hose (usa)	Intake	2
90460-49058-00	Clamp, Hose (278-14455-00) 2	Intake	2
2L0-14453-00-00	Joint, Air Cleaner 1	Intake	2
90413-40002-00	Way, 3	Intake	1
90467-14015-00	Clip (90467-14056)	Intake	2
90460-45040-00	Clamp, Hose (90460-45104)	Intake	2
1L9-15620-01-93	Kick Crank Assembly Chrome Plated	Kickstarter	1
278-15621-00-00	Boss, Kick Crank Alternate Part	Kickstarter	1
93507-32009-00	Ball (7/32 Inch) 1	Kickstarter	1
90501-12081-00	Spring, Boss Stopper (278-15622-00)	Kickstarter	1
90201-15340-00	Washer, Special (15.5-25-1.6)	Kickstarter	1
93430-10016-00	Clip Optional, Right Change, Left Brake Part	Kickstarter	1
156-15618-01-00	Cover, Kick Lever Alternate Part	Kickstarter	1
97321-08030-00	Bolt, Hexagon	Kickstarter	1
1L9-15660-00-00	Kick Axle Assembly	Kickstarter	1
136-17417-00-10	Shim, Main Axle (17.2-28-1)	Kickstarter	1
371-15641-01-00	Gear, Kick (23t)	Kickstarter	1
90468-26045-00	Clip (278-15687-00)	Kickstarter	1
278-15676-00-00	Cover, Kick Spring	Kickstarter	1
90508-30051-00	Spring, Torsion (278-15665-00)	Kickstarter	1
371-15666-00-00	Spacer	Kickstarter	1
90201-20266-00	Washer, Gear Hold (20-25-1) (132-17216-00-00)	Kickstarter	1
93410-20009-00	Circlip (21.2-29-2)	Kickstarter	1
93102-20108-00	Oil Seal Alternate Part	Kickstarter	1
1L9-13300-00-00	Oil Pump Assembly	Oil Pump	1

1L9-13483-00-00	Plunger, Relief	Oil Pump	1
1L9-13484-00-00	Spring, Relief	Oil Pump	1
1L9-13486-00-00	Retainer, Relief Valve	Oil Pump	1
91401-25030-00	Pin, Cotter (91401-25025)	Oil Pump	1
1L9-13341-01-00	Gear, Oil Pump Idle (32t/20t)	Oil Pump	1
91316-08045-00	Bolt (91318-08045)	Oil Pump	1
91318-08035-00	Bolt, Hexagon Socket Head	Oil Pump	2
91810-03014-00	Pin, Dowel (10-8.5-14)	Oil Pump	1
3X8-13411-00-00	Strainer, Oil	Oil Pump	1
3X8-13415-00-00	Seal, Oil Strainer	Oil Pump	1
1L9-13417-00-00	Cover, Strainer	Oil Pump	1
1L9-13414-00-00	Gasket, Strainer Cover	Oil Pump	1
97301-05016-00	Bolt, Hexagon (97301-05015)	Oil Pump	6
92901-05600-00	Washer, Plate Alternate Parts	Oil Pump	6
1L9-13447-01-00	Cover, Oil Element	Oil Pump	1
1L9-13440-91-00	Element, Oil Cleaner (119-13440-90)	Oil Pump	1
90480-23193-00	Grommet	Oil Pump	2
93501-02018-00	Ball (1/2 Inch)	Oil Pump	1
90501-12413-00	Spring, Compression	Oil Pump	1
91609-20018-00	Pin, Spring	Oil Pump	1
1L9-13340-01-00	Bolt, Union (90401-20055)	Oil Pump	1
93210-16325-00	O-Ring (2.4-15.8)	Oil Pump	1
93210-88324-00	O-Ring (4.1-87.8)	Oil Pump	1
90201-21608-00	Washer, Plate	Oil Pump	1
90501-20422-00	Spring, Compression	Oil Pump	1
4R4-81671-10-00	Base, Pickup(3f9-81671-10)	Pickup Coil - Govern	1
3F9-81673-10-00	Rotor	Pickup Coil - Govern	1
97801-06014-00	Screw, Pan Head	Pickup Coil - Govern	2
92903-06200-00	Washer, Push Lever (6.2-15-1) (122-16359-00)	Pickup Coil - Govern	2
97301-06030-00	Bolt (97303-06030)	Pickup Coil - Govern	1
90201-06060-00	Washer, Plain (6-18-1.6) (132-18338-00)	Pickup Coil - Govern	1
3F9-22110-00-33	Rear Arm Comp Yamaha Black	Rear Arm - Suspens	1
90386-22029-00	Bushing, Rear Arm (256-22123-01)	Rear Arm - Suspens	2
341-22184-00-00	Bushing (447-22184-00)	Rear Arm - Suspens	1
371-22128-00-00	Cover, Thrust 1 (371-22128-01)	Rear Arm - Suspens	2
371-22141-00-00	Shaft, Pivot	Rear Arm - Suspens	1
93700-06004-00	Nipple, Grease Alternate Parts	Rear Arm - Suspens	2
90215-14113-00	Washer, Lock (256-22149-00)	Rear Arm - Suspens	1
240-22127-00-00	Shim, Rear Arm (26-34-0.3) (156-22127-00) U. N.	Rear Arm - Suspens	2
90170-14174-00	Nut, Hexagon	Rear Arm - Suspens	1
3F9-22311-00-93	Case, Chain (92501-06015) Chrome Plated	Rear Arm - Suspens	1
92503-06015-00	Screw, Pan Head (92501-06016-00) 008171-	Rear Arm - Suspens	2
92903-06100-00	Washer, Spring Use With 214-15121-01-00 To 291-15121-00-00 Crankcase	Rear Arm - Suspens	2
92901-06600-00	Washer, Plate Alternate Parts (u.s.a. Only)	Rear Arm - Suspens	2
3F9-22210-00-93	Shock Absorber Assembly, Rear Chrome Plated	Rear Arm - Suspens	2
2L0-22212-00-00	Spring	Rear Arm - Suspens	2
3G1-85137-00-00	Base, Reflector Rear Alternate Part	Rear Arm - Suspens	2
3G1-85130-00-00	Rear Reflector Assembly	Rear Arm - Suspens	2
95301-05600-00	Nut, Adjust Plate (137-13139-00) (137-13139-01) Iso	Rear Arm - Suspens	2
92901-05200-00	Washer, Plain Alternate Prts	Rear Arm - Suspens	2
90201-10140-00	Washer, Rear Cushion (10.5-27-2) (136-22243-00)	Rear Arm - Suspens	2
90176-10013-00	Nut, Crown (90176-10027)	Rear Arm - Suspens	2
3F9-22241-00-00	Bolt 1	Rear Arm - Suspens	2
3F9-25338-00-98	Cast Wheel, Rear Low Gloss Black	Rear Wheel	1
93306-30309-00	Bearing (b6303z) (93306-30303-00)	Rear Wheel	1
93306-30416-00	Bearing (93306-30423)	Rear Wheel	1
93104-27026-00	Oil Seal (s0-27-52-5)	Rear Wheel	1
3F9-25317-00-00	Spacer, Bearing	Rear Wheel	1
1A1-25115-00-00	Flange, Spacer (148-25315-00)	Rear Wheel	1

1A1-25377-00-00	Collar, Wheel	Rear Wheel	1
1U4-25364-00-00	Damper	Rear Wheel	4
1J3-25437-20-00	Gear, Sprocket Wheel (37t)	Rear Wheel	1
90387-20565-00	Collar (23.5-35.5-5.5)	Rear Wheel	4
1J3-25412-00-00	Washer, Plate	Rear Wheel	2
95302-12700-00	Nut, Hexagon	Rear Wheel	4
90201-66585-00	Washer, Plate	Rear Wheel	1
93410-65040-00	Circlip, S-Type	Rear Wheel	1
1L9-25026-00-98	Brake Shoe Plate Assembly Low Gloss Black	Rear Wheel	1
90480-10068-00	Grommet Alternate Parts	Rear Wheel	1
1L9-25330-01-00	Brake Shoe Comp	Rear Wheel	2
90507-20002-00	Spring, Brake Shoe Return (246-25333-00)	Rear Wheel	2
214-25351-00-00	Camshaft (214-25351-01)	Rear Wheel	1
148-25353-00-00	Shim, Camshaft (14.2-24-0.5)	Rear Wheel	1
148-25359-00-00	Oil Seal (s0-14-20-3) (93104-14044)	Rear Wheel	1
1L9-25355-00-00	Lever, Camshaft 1	Rear Wheel	1
90101-06291-00	Bolt (90101-06495)	Rear Wheel	1
94112-16407-00	Tire Yokohama	Rear Wheel	1
93900-00001-00	Valve, Rim (16024 101) U. R. Bridgestone	Rear Wheel	1
93900-00002-00	Valve, Rear (tubeless Tire) 166556~	Rear Wheel	1
1A1-25399-00-00	Balancer, Wheel (10g) U. N.	Rear Wheel	1
1A1-25398-01-00	Balancer, Wheel (1a1-25398-00) U.n. 20g	Rear Wheel	1
2M0-25399-00-00	Balance, Wheel Un 30g Se 114241~	Rear Wheel	1
94580-10102-00	Chain, Drive (did50ds 102l)	Rear Wheel	1
94685-30011-00	Joint, Chain	Rear Wheel	1
168-25389-00-00	Puller, Chain (r.h.) (170)	Rear Wheel	2
90101-08034-00	Bolt, Chain Puller (168-25379-00)	Rear Wheel	2
95301-08700-00	Nut (92801-08300) For Folding Footrest	Rear Wheel	2
3F9-25371-00-00	Bar, Tension	Rear Wheel	1
90109-08375-00	Bolt, Tension Bar 1 (168-25373-00)	Rear Wheel	1
90109-08184-00	Bolt, Tension Bar 2 (168-25378-00)	Rear Wheel	1
92901-08600-00	Washer, Plate Alternate Parts (u.s.a. Only)	Rear Wheel	2
92903-08100-00	Washer, Spring (92902-08100) (optional Parts)	Rear Wheel	1
95301-08700-00	Nut (92801-08300) For Folding Footrest	Rear Wheel	1
90170-08158-00	Nut (90170-08260)	Rear Wheel	1
91401-20015-00	Pin, Cotter (2-12) (91451-20012)	Rear Wheel	2
1J3-25381-00-00	Axle, Wheel (2v6-25381-00)	Rear Wheel	1
3F9-25383-00-00	Collar, Wheel	Rear Wheel	1
90171-14020-00	Nut, Wheel Shaft (214-25182-01)	Rear Wheel	1
91401-30030-00	Pin, Cotter (91401-30022) Original	Rear Wheel	1
90387-17551-00	Collar, Wheel Shaft	Rear Wheel	1
1L9-25367-00-00	Cover, Hub Dust	Rear Wheel	1
92901-14200-00	Washer, Plain	Rear Wheel	1
3F9-W2472-00-00	Double Seat Assembly	Seat	1
3F9-24731-00-00	Cover, Double Seat	Seat	1
3F9-24748-00-00	Bracket, Seat	Seat	2
95302-06600-00	Nut (usa)	Seat	8
92903-06100-00	Washer, Spring Use With 214-15121-01-00 To 291-15121-00-00 Crankcase	Seat	4
1T4-24741-00-00	Pad, Seat Front	Seat	2
395-28185-00-00	Lid	Seat	1
371-27114-00-00	Stopper, Main Stand (usa)	Seat	2
3F9-24754-00-00	Hook, Seat	Seat	1
90508-20412-00	Spring, Torsion	Seat	1
1J7-24723-00-00	Damper, Seat (119-24723-00)	Seat	4
90201-06765-00	Washer, Plate	Seat	4
90387-06595-00	Spacer (90560-07007)	Seat	4
3F9-24718-00-00	Bracket, Seat (3f9-24718-01)	Seat	2
3J2-24741-00-00	Pad, Seat	Seat	2
3F9-24737-00-00	Damper, Seat	Seat	2

90387-06554-00	Collar (6.5-10.5-20.5)	Seat	2
97301-06030-00	Bolt (97303-06030)	Seat	2
90201-06074-00	Washer, Special (6.5-28-1.6) (248-21757-00)	Seat	2
1M3-27114-00-00	Stopper, Main Stand (102-27114-00)	Seat	2
3F9-24705-00-00	Seat Lock Assembly	Seat	1
92706-06030-00	Screw, Flat Head	Seat	1
3J3-2475H-00-00	Bracket, Seat Lever 1	Seat	1
3F9-2475J-00-00	Bracket, Seat Lever 2	Seat	1
92506-06012-00	Screw, Pan Head	Seat	4
92906-06600-00	Washer, Plate 4	Seat	4
3F9-24776-00-00	Lever, Seat	Seat	1
3F9-24758-00-00	Spring	Seat	1
92096-08600-00	Washer, Plate	Seat	1
91401-25012-00	Pin, Cotter	Seat	1
3F9-21683-00-00	Plate, Specification	Seat	1
1L9-18540-00-00	Shift Cam Assembly	Shift Cam Fork	1
278-18542-00-00	Point, Neutral	Shift Cam Fork	1
90501-06022-00	Spring, Compression (278-18545-00)	Shift Cam Fork	1
278-18566-00-00	Plate, Side 2	Shift Cam Fork	1
98701-05012-00	Screw, Flat Head	Shift Cam Fork	1
93604-08071-00	Pin, Dowel (4.0-8.0)	Shift Cam Fork	1
93604-14012-00	Pin, Dowel (4.0-13.8)	Shift Cam Fork	1
93315-23612-00	Bearing, Cylindrical (93315-23607)	Shift Cam Fork	1
328-18185-00-00	Segment	Shift Cam Fork	1
93604-22050-00	Pin, Dowel (40-22) 514910~	Shift Cam Fork	6
328-18352-10-00	Inactive Part Number	Shift Cam Fork	1
328-18561-00-00	Plate, Side 1	Shift Cam Fork	1
98701-05020-00	Screw, Flat Head	Shift Cam Fork	1
1L9-18141-00-00	Plate, Stopper	Shift Cam Fork	1
93410-30012-00	Circlip (s-30) (yg9-00006-35-1g)	Shift Cam Fork	1
328-18562-00-00	Plate, Stopper 2	Shift Cam Fork	1
92701-06015-00	Screw, Flat Head	Shift Cam Fork	2
328-18179-00-00	Guide, Change Lever	Shift Cam Fork	1
98501-05010-00	Screw, Pan Head (98503-05008) Used On 235-15411-0C	Shift Cam Fork	2
328-18511-01-00	Fork, Shift 1 (328-18511-00)	Shift Cam Fork	2
328-18512-01-00	Fork, Shift 2 (328-18512-00)	Shift Cam Fork	2
90250-08017-00	Pin, Cam Follower (278-18552-00) Lt3 066631~ Ltmx 113021~	Shift Cam Fork	4
278-18531-00-00	Bar, Shift Fork Guide 1	Shift Cam Fork	1
278-18535-00-00	Bar, Shift Fork Guide 2	Shift Cam Fork	1
93430-10016-00	Clip Optional, Right Change, Left Brake Part	Shift Cam Fork	4
90338-22021-00	Plug, Special Shape (371-18149-	Shift Cam Fork	2
278-18547-02-00	Stopper, Cam (278-18547-01)	Shift Cam Fork	1
90501-10062-00	Spring, Compression (278-18557-00)	Shift Cam Fork	1
90149-14031-00	Screw (278-18577-03)	Shift Cam Fork	1
137-15353-00-00	Gasket, Drain Plug (14.0-21.0-1.5)	Shift Cam Fork	1
328-18128-00-00	Bracket	Shift Shaft - Pedal	1
90508-08007-00	Spring, Torsion (214-18123-00)	Shift Shaft - Pedal	1
328-18151-00-00	Lever, Change 3	Shift Shaft - Pedal	2
93430-07012-00	Circlip (e-7)	Shift Shaft - Pedal	1
214-18178-00-00	Roller, Change Lever (1)	Shift Shaft - Pedal	1
90149-06017-00	Screw, Adjusting (214-18186-00) E/#1 1572-	Shift Shaft - Pedal	1
95301-06600-00	Nut, Hexagon 250 Frame #200815- 400 Frame #008894-	Shift Shaft - Pedal	1
92903-06100-00	Washer, Spring Use With 214-15121-01-00 To 291-15121-00-00 Crankcase	Shift Shaft - Pedal	1
90508-32055-00	Spring, Shaft Return (278-18124-00)	Shift Shaft - Pedal	1
278-18127-00-00	Screw, Adjusting	Shift Shaft - Pedal	1
90215-08015-00	Washer, Lock (214-18139-00) M4-046	Shift Shaft - Pedal	1
278-18101-01-00	Shift Shaft Assembly 1	Shift Shaft - Pedal	1
93102-12106-00	Oil Seal (s-12-22-5) (93101-12004)	Shift Shaft - Pedal	1
90201-12575-00	Washer, Change Shaft (12-25.5-1.5) (137-18137-00)	Shift Shaft - Pedal	1

93430-10016-00	Clip Optional, Right Change, Left Brake Part	Shift Shaft - Pedal	1
278-18131-00-00	Boot, Sealing	Shift Shaft - Pedal	1
2L1-18111-00-00	Pedal, Change (119-18111-02-93)	Shift Shaft - Pedal	1
97321-06020-00	Bolt Must Use W/kick Crank: 367-00	Shift Shaft - Pedal	1
132-18113-01-00	Cover, Change Pedal (132-18113-00)	Shift Shaft - Pedal	1
3F9-21240-00-00	Box Comp	Side Cover	1
90480-14102-00	Damper, Battery Box 1 (6.5-20-1.6) (214-21717-00)	Side Cover	2
90387-07390-00	Collar (7-10-11.5) (214-21633-00)	Side Cover	2
90201-06067-00	Washer, Leg Shield 2 (6.5-20-1.6) (116-28324-00-00)	Side Cover	2
97301-06025-00	Bolt, Hexagon (97302-06025)	Side Cover	2
1J7-21746-00-00	Damper, Battery Box	Side Cover	2
1L9-21776-01-00	Band, Tank Fitting	Side Cover	2
92501-06030-00	Screw Pan Head (92501-06030-00)	Side Cover	2
92901-06600-00	Washer, Plate Alternate Parts (u.s.a. Only)	Side Cover	2
4R4-21711-00-2J	Cover, Side (lh) (3f9-21711-00-2j) Ur Black Red	Side Cover	1
3F9-21711-00-4H	Cover, Side (lh) U. R. Cardinal Red	Side Cover	1
3F9-21781-00-00	Emblem 1	Side Cover	1
90183-04005-00	Nut (116-28317-01) Candy Orange	Side Cover	2
90202-04003-00	Damper, Emblem (174-28316-00)	Side Cover	2
3F9-21721-00-2J	Cover, Side (rh) U. R. Black Red	Side Cover	1
3F9-21721-00-4H	Cover, Side (rh) U. R. Cardinal Red	Side Cover	1
3F9-21782-00-00	Emblem 2	Side Cover	1
90183-04005-00	Nut (116-28317-01) Candy Orange	Side Cover	2
90202-04003-00	Damper, Emblem (174-28316-00)	Side Cover	2
90480-12053-00	Grommet, Side Cover	Side Cover	4
90480-01141-00	Damper, Side Cover 2 (371-21747-00)	Side Cover	2
3F9-83519-01-00	Bracket, Meter (3f9-83519-00)	Speedometer - Tach	1
3F9-83570-A0-00	Speedometer Assembly (3w5-83570-F0)	Speedometer - Tach	1
584-83578-71-00	Knob, Trip Meter	Speedometer - Tach	1
2H7-83556-00-00	Socket Cord Assembly 4	Speedometer - Tach	1
3F9-83536-A0-00	Socket, Motor	Speedometer - Tach	1
123-83516-21-00	Bulb, Pilot (15v-3w) (123-83516-20)	Speedometer - Tach	1
3W5-83540-F0-00	Tachometer Assembly	Speedometer - Tach	1
3F9-83520-A0-00	Socket Assembly	Speedometer - Tach	1
123-83516-21-00	Bulb, Pilot (15v-3w) (123-83516-20)	Speedometer - Tach	2
2J2-83507-00-00	Cover, Speedometer	Speedometer - Tach	1
2J2-83508-00-00	Cover, Tachometer	Speedometer - Tach	1
95301-05800-00	Nut, Crown	Speedometer - Tach	4
90201-05031-00	Washer, Special (5.5-15-1.0) (256-82517-00)	Speedometer - Tach	4
584-83523-00-00	Damper, Meter Cover Fitting	Speedometer - Tach	4
3H3-83513-00-00	Damper, Meter (584-83513-01)	Speedometer - Tach	2
584-83546-00-00	Bolt	Speedometer - Tach	4
92903-06200-00	Washer, Push Lever (6.2-15-1) (122-16359-00)	Speedometer - Tach	4
92903-06100-00	Washer, Spring Use With 214-15121-01-00 To 291-15121-00-00 Crankcase	Speedometer - Tach	4
95301-06800-00	Nut, Crown For Use With Old Silencer Only	Speedometer - Tach	4
2L0-83568-A0-00	Pilot Box, Upper	Speedometer - Tach	1
98501-04008-00	Screw, Pan Head (98503-04008) Used On All 211-23100-Xx, Front Fork	Speedometer - Tach	1
92901-04100-00	Washer, Spring Used On 168-81200-22	Speedometer - Tach	1
92901-04600-00	Washer, Spring (92901-04100-00)	Speedometer - Tach	1
2G2-83569-A0-00	Pilot Box, Under	Speedometer - Tach	1
98506-04012-00	Screw, Pan Head	Speedometer - Tach	4
92906-04100-00	Washer, Spring 006301-	Speedometer - Tach	4
92906-04600-00	Washer, Plate	Speedometer - Tach	4
2L0-83509-A0-00	Socket Cord Assembly, Indicator Lamp	Speedometer - Tach	1
123-83516-21-00	Bulb, Pilot (15v-3w) (123-83516-20)	Speedometer - Tach	3
1A0-83523-00-00	Damper	Speedometer - Tach	4
90201-06067-00	Washer, Leg Shield 2 (6.5-20-1.6) (116-28324-00-00)	Speedometer - Tach	2
92903-06100-00	Washer, Spring Use With 214-15121-01-00 To 291-15121-00-00 Crankcase	Speedometer - Tach	2
95301-06600-00	Nut, Hexagon 250 Frame #200815- 400 Frame #008894	Speedometer - Tach	2

2L0-83550-00-00	Speedometer Assembly	Speedometer - Tach	1
2L0-83560-00-00	Tachometer Cable Assembly	Speedometer - Tach	1
3F9-27111-00-33	Stand, Main Yamaha Black	Stand - Footrest	1
90506-45063-00	Spring, Tension (168-27116-00)	Stand - Footrest	1
90109-10440-00	Bolt	Stand - Footrest	2
95601-10100-00	Nut, U (95602-10100-00) 1	Stand - Footrest	2
1L9-27211-00-93	Pedal, Brake Chrome Plated	Stand - Footrest	1
90109-06468-00	Bolt, Hexagon	Stand - Footrest	1
92903-06100-00	Washer, Spring Use With 214-15121-01-00 To 291-15121-00-00 Crankcase	Stand - Footrest	1
90153-06008-00	Screw, Cross Recess (341-27217-00)	Stand - Footrest	1
90170-06184-00	Nut (90170-06273)	Stand - Footrest	1
3F9-27212-00-00	Shaft, Brake Pedal	Stand - Footrest	1
90508-35315-00	Spring, Torsion	Stand - Footrest	1
3F9-27231-00-00	Rod, Brake	Stand - Footrest	1
90240-06006-00	Pin, Link Joint (248-27228-00)	Stand - Footrest	1
92901-06600-00	Washer, Plate Alternate Parts (u.s.a. Only)	Stand - Footrest	1
91401-25015-00	Pin, Cotter (91401-25012)	Stand - Footrest	1
90501-10245-00	Spring, Compression (180-27236-00)	Stand - Footrest	1
90249-12008-00	Pin, With Hole (307-18118-00)	Stand - Footrest	1
90179-06176-00	Nut, Adjusting (206-27238-00) (90179-06153)	Stand - Footrest	1
1L9-27311-02-33	Stand, Side (119-27311-00)	Stand - Footrest	1
90102-10006-00	Bolt, Side Stand Use With Frame Comp 1j7-21110-01-33	Stand - Footrest	1
90171-10012-00	Nut, Castle (92802-10500)	Stand - Footrest	1
91490-20025-00	Pin, Cotter (91403-20025) (91401-20025)	Stand - Footrest	1
90506-26270-00	Spring, Tension (90506-28100)	Stand - Footrest	1
3J3-27314-00-00	Stopper	Stand - Footrest	1
3F9-27410-00-93	Front Footrest Assembly (lh) Chrome-Plated	Stand - Footrest	1
1T3-27451-00-00	Bracket, Footrest Left	Stand - Footrest	1
1J7-27413-01-00	Cover, Footrest Right	Stand - Footrest	1
90508-20023-00	Spring, Return (214-27418-00) Pn253	Stand - Footrest	1
90243-08006-00	Pin, Clevis (214-47418-00) Pn253	Stand - Footrest	1
90201-06042-00	Washer, Special (6.5-12-2.0) (214-27417-00)	Stand - Footrest	1
90480-20195-00	Grommet	Stand - Footrest	2
90209-08193-00	Washer	Stand - Footrest	2
2L0-27417-00-00	Washer, Footrest	Stand - Footrest	2
97313-08016-00	Bolt, Hexagon Alternate Parts	Stand - Footrest	2
92903-08100-00	Washer, Spring (92902-08100) (optional Parts)	Stand - Footrest	2
3F9-27420-00-93	Front Footrest Assembly (rh) Chrome-Plated	Stand - Footrest	1
1T3-27461-00-00	Bracket, Footrest Right	Stand - Footrest	1
1J7-27413-01-00	Cover, Footrest Right	Stand - Footrest	1
90508-20023-00	Spring, Return (214-27418-00) Pn253	Stand - Footrest	1
90243-08006-00	Pin, Clevis (214-47418-00) Pn253	Stand - Footrest	1
90201-06042-00	Washer, Special (6.5-12-2.0) (214-27417-00)	Stand - Footrest	1
90480-20195-00	Grommet	Stand - Footrest	2
90209-08193-00	Washer	Stand - Footrest	2
2L0-27417-00-00	Washer, Footrest	Stand - Footrest	2
97313-08016-00	Bolt, Hexagon Alternate Parts	Stand - Footrest	2
92903-08100-00	Washer, Spring (92902-08100) (optional Parts)	Stand - Footrest	2
2L0-27432-01-00	Bracket, Rear Footrest Left (210-27432-00)	Stand - Footrest	1
447-27431-00-00	Footrest, Rear Left	Stand - Footrest	1
447-27433-00-00	Cover, Right Rear Footrest	Stand - Footrest	1
90209-18070-00	Washer, Plate (447-27437-00)	Stand - Footrest	1
90240-06042-00	Pin, With Hole	Stand - Footrest	1
91401-16015-00	Pin, Cotter Alternate Parts	Stand - Footrest	1
95701-10100-00	Nut, Flange	Stand - Footrest	1
262-21399-00-00	Cap, Tool Box	Stand - Footrest	1
92903-10100-00	Washer, Spring Use With Crank (l.h.) 214-11412-00-00	Stand - Footrest	1
2L0-27442-01-00	Bracket, Rear Footrest Right	Stand - Footrest	1
447-27441-00-00	Footrest, Rear 2 (447-27441-01)	Stand - Footrest	1

447-27433-00-00	Cover, Right Rear Footrest	Stand - Footrest	1
90209-18070-00	Washer, Plate (447-27437-00)	Stand - Footrest	1
90240-06042-00	Pin, With Hole	Stand - Footrest	1
91401-16015-00	Pin, Cotter Alternate Parts	Stand - Footrest	1
95701-10100-00	Nut, Flange	Stand - Footrest	1
262-21399-00-00	Cap, Tool Box	Stand - Footrest	1
92903-10100-00	Washer, Spring Use With Crank (l.h.) 214-11412-00-00	Stand - Footrest	1
1L9-15519-00-00	Sprocket, Starter 2	Starter Clutch	1
94552-19058-00	Chain, Starter (did219h2 58l)	Starter Clutch	1
1L9-15591-00-00	Guide, Starter Chain	Starter Clutch	1
1L9-15592-01-00	Guide, Starter Sprocket	Starter Clutch	1
97301-06014-00	Bolt, Hexagon (97301-06015) Se 114241~	Starter Clutch	1
341-15580-06-00	Starter Clutch Outer Assembly	Starter Clutch	1
90501-03298-00	Spring, Starter Clutch Roller (341-15584-03)	Starter Clutch	3
341-15583-05-00	Cap, Starter Clutch Spring (341-15583-04) 005426-Tx500	Starter Clutch	3
93615-12088-00	Pin, Dowel (15-15)	Starter Clutch	3
1L9-15589-00-00	Plate, Starter Clutch Cover	Starter Clutch	1
91310-08015-00	Bolt, Hexagon Socket Head	Starter Clutch	3
1L9-15436-00-00	Cover, Starting Motor	Starter Clutch	1
1L9-15446-00-00	Gasket, Starting Motor Cover	Starter Clutch	1
90105-06069-00	Bolt, Washer Based Head Hexagon	Starter Clutch	2
1L9-81800-61-00	Starting Motor Assembly (1I9-81800-60)	Starting Motor	1
371-81845-20-00	Plate	Starting Motor	1
371-81844-20-00	Gasket	Starting Motor	1
371-81809-20-00	Washer, Kit	Starting Motor	1
1L9-81850-20-00	Armature Assembly	Starting Motor	1
1L9-81810-60-00	Stator Assembly	Starting Motor	1
1L9-81840-60-00	Brush Holder Assembly	Starting Motor	1
1L9-81811-60-00	Brush (+)	Starting Motor	1
1L9-81812-60-00	Brush (-)	Starting Motor	1
1L9-81813-20-00	Spring, Brush	Starting Motor	2
98501-03008-00	Screw, Pan Head With Washer (97602-03108)	Starting Motor	2
92903-03100-00	Washer, Belleville (92901-03100)	Starting Motor	2
371-81847-20-00	O-Ring	Starting Motor	1
371-81826-20-00	Bolt (4x7-8l826-60)	Starting Motor	2
1L9-81847-60-00	O-Ring	Starting Motor	1
1L9-15518-60-00	Sprocket, Starter (13t)	Starting Motor	1
97301-06060-00	Bolt	Starting Motor	1
97301-06055-00	Bolt, Hexagon 005001~ M7-021	Starting Motor	1
156-23411-00-00	Race, Ball 1 032509	Steering	1
164-23462-00-00	Seal, Steering (usa)	Steering	1
2L0-23435-00-98	Crown, Handle Low Gloss Black	Steering	1
97306-08055-00	Bolt	Steering	2
95306-08800-00	Nut (crown)	Steering	2
92906-08600-00	Washer, Plate Ca Only	Steering	4
156-23412-00-00	Race, Ball 2 032509	Steering	1
93501-04011-00	Ball (1/4 Inch) (93501-04004)	Steering	19
183-23411-00-00	Race, Ball (1)	Steering	1
183-23412-00-00	Race, Ball (2)	Steering	1
93501-04011-00	Ball (1/4 Inch) (93501-04004)	Steering	19
136-23415-00-00	Cover, Ball Race	Steering	1
90179-25033-00	Nut, Steering Fitting (137-23454-00)	Steering	1
90105-14102-00	Bolt, Round Hexagon (90106-14017)	Steering	1
1E6-23442-00-00	Holder, Handle Lower (3r4-23442-00-98) Low Gloss Black	Steering	2
256-23434-01-00	Rubber, Bushing 017354~	Steering	4
90209-12151-00	Washer, Special Shape	Steering	2
90201-10149-00	Washer, Special (256-23444-00) 017354~ Pn320	Steering	2
92903-10100-00	Washer, Spring Use With Crank (l.h.) 214-11412-00-00	Steering	2
95301-10700-00	Nut, Hexagon (95302-10700)	Steering	2

90468-12006-00	Clip, Tension Bar (136-25375-00)	Steering	2
1E6-23441-10-98	Holder, Handle Upper Lgb - Color Info (lgb:low Gloss Black:0098)	Steering	2
90106-08032-00	Bolt, Round Hexagon	Steering	4
92901-08600-00	Washer, Plate Alternate Parts (u.s.a. Only)	Steering	4
1L9-17841-00-00	Gear, Driven (15t)	Tachometer Gear	1
1L9-17811-00-00	Housing, Tachometer Gear	Tachometer Gear	1
93440-12051-00	Circlip, Outer	Tachometer Gear	1
90201-06605-00	Washer, Plate	Tachometer Gear	1
93109-07016-00	Oil Seal (sd0-6.5-14.5-7.0)	Tachometer Gear	1
98503-05025-00	Screw, Pan Head Used On 168-82910-09-00 156-82920-10-94	Tachometer Gear	1
3G1-84710-60-00	Tail Light Unit Assembly	Taillight	1
256-84714-61-00	Bulb, Tail Lamp (12v-32/3cp) (256-84714-60)	Taillight	2
1A8-84721-61-00	Lens, Taillight	Taillight	1
1A0-84723-60-00	Gasket, Tail Lamp	Taillight	1
3G1-84711-60-00	Base, Taillight	Taillight	1
1A0-84724-60-00	Screw, Lens Fitting Canada	Taillight	2
3G1-84712-00-00	Seat, Base	Taillight	1
90109-06548-00	Bolt	Taillight	2
2H7-84754-00-00	Washer, Special (437-84525-60) 02260~ Canada	Taillight	2
3G1-84712-60-00	Seat, Base	Taillight	2
3F9-84745-60-00	License Light Unit Assembly	Taillight	1
3F9-84749-00-00	Body, License Light	Taillight	1
3F9-84741-00-00	Base, License Light	Taillight	1
3F9-84744-00-00	Bulb (12v-3.8w) (3g1-84744-00)	Taillight	2
3F9-84751-00-93	Bracket, License Chrome Plated	Taillight	1
3F9-84553-00-00	Damper	Taillight	2
3F9-84754-00-00	Washer, Special (3gl-84754-00)	Taillight	2
3F9-84757-00-00	Collar, License Bracket	Taillight	2
3F9-84742-00-00	Seat, Base	Taillight	1
95303-05800-00	Nut, Crown (95304-05800)	Taillight	2
3F9-84753-00-00	Damper	Taillight	1
3G1-84753-60-00	Damper	Taillight	3
92903-08200-00	Washer, Plain (92901-08200) Optional Parts	Taillight	3
92903-06100-00	Washer, Spring Use With 214-15121-01-00 To 291-15121-00-00 Crankcase	Taillight	3
90109-06562-00	Bolt	Taillight	1
90109-06571-00	Bolt	Taillight	2
95301-06600-00	Nut, Hexagon 250 Frame #200815- 400 Frame #008894-	Taillight	3
1L9-17401-00-00	Main Axle Assembly (14t)	Transmission	1
168-17428-01-03	Shim, Drive Axle (25-34-0-3) Canada Only Ur	Transmission	1
168-17428-01-05	Shim, Drive Axle (25-36-1.5) (168-17428-00) Used On (168-17421-00), Transmission	Transmission	1
93305-20502-00	Bearing (93305-20508-00)	Transmission	1
93440-52009-00	Circlip (520 Special)	Transmission	1
1L9-17141-00-00	Gear, 4th Pinion (24t)	Transmission	1
90201-25287-00	Washer, Plate (256-17154-00-10) 1204949-	Transmission	1
93440-25019-00	Circlip (e-25 Special) (93440-25008)	Transmission	3
1L9-17131-00-00	Gear, 3rd Pinion (21t)	Transmission	1
1L9-17161-00-00	Gear, 6th Pinion (30t)	Transmission	1
90209-21105-00	Washer, Gear Hold 1 (328-17216-00) Alternate Parts	Transmission	2
1A1-17121-00-00	Gear, 2nd Pinion (18t) (360-17121-00)	Transmission	1
1L9-17151-00-00	Gear, 5th Pinion (26t)	Transmission	1
90201-20266-00	Washer, Gear Hold (20-25-1) (132-17216-00-00)	Transmission	2
93410-20009-00	Circlip (21.2-29-2)	Transmission	1
93311-22027-00	Bearing (20-30-15) (93311-22005)	Transmission	1
93450-32042-00	Circlip, Inner	Transmission	1
1L9-17420-00-00	Drive Axle Assembly (25t)	Transmission	1
1L9-17221-00-00	Gear, 2nd Wheel (32t)	Transmission	1
90209-21105-00	Washer, Gear Hold 1 (328-17216-00) Alternate Parts	Transmission	3
93440-25019-00	Circlip (e-25 Special) (93440-25008)	Transmission	3
1L9-17261-00-00	Gear, 6th Wheel (26t)	Transmission	1

2A2-17231-00-00	Gear, 3rd Wheel Engine 0052015	Transmission	1
2A2-17241-00-00	Gear, 4th Wheel Engine 052015	Transmission	1
1L9-17210-00-00	Gear, 1st Wheel Assembly (35t)	Transmission	1
90201-20266-00	Washer, Gear Hold (20-25-1) (132-17216-00-00)	Transmission	1
93410-20009-00	Circlip (21.2-29-2)	Transmission	1
93311-42045-00	Bearing, Cylindrical (93311-42032)	Transmission	1
278-17425-00-00	Circlip 2 (u49)	Transmission	1
168-17428-01-03	Shim, Drive Axle (25-34-0-3) Canada Only Ur	Transmission	1
168-17428-01-05	Shim, Drive Axle (25-36-1.5) (168-17428-00) Used On (168-17421-00), Transmission	Transmission	1
93306-30506-00	Bearing (b6305n Special) (93306-30504)	Transmission	1
278-17424-01-00	Circlip 1 (278-17424-00)	Transmission	1
93102-35109-00	Oil Seal (sd-35-62-6) (93102-35054)	Transmission	1
90387-25192-00	Collar, Distance (25.0-35.0-17.5) (169-17462-00)	Transmission	1
1A1-17461-60-00	Sprocket, Drive (16t) U. R.	Transmission	1
90215-21121-00	Washer, Lock (usa)	Transmission	1
90179-18020-00	Nut, Lock (152-17463-00)	Transmission	1
1L9-12111-03-00	Valve, Intake (1I9-12111-02-00)	Valve	2
1L9-12121-02-00	Valve, Exhaust	Valve	2
1L9-12116-00-00	Seat, Valve Spring	Valve	4
1L9-12113-00-00	Spring, Valve Inner	Valve	4
1L9-12114-00-00	Spring, Valve Outer	Valve	4
1L9-12119-00-00	Seal, Valve Stem Oil	Valve	4
1L9-12117-00-00	Retainer, Valve Spring	Valve	4
1J7-12118-00-00	Lock, Valve Spring Retainer	Valve	8
1L9-12151-01-00	Arm, Valve Rocker (1I9-12151-00)	Valve	4
1L9-12156-01-00	Shaft, Rocker Arm (1I9-12156-00)	Valve	4
1L9-12159-01-00	Screw, Valve Adjusting (1I9-12159-00)	Valve	4
90170-06128-00	Nut, Hexagon (371-12158-00)	Valve	4