



Wiring diagram for Yamaha XS250 and 400 models

COLOR CODE			
B	Black	B/R	Black/Red
Ch	Chocolate	G/R	Green/Red
G	Green	G/Y	Green/Yellow
L	Blue	L/G	Blue/Green
O	Orange	L/W	Blue/White
P	Pink	L/Y	Blue/Yellow
R	Red	R/L	Red/Blue
Br	Brown	R/W	Red/White
W	White	R/Y	Red/Yellow
Y	Yellow	W/G	White/Green
Dg	Dark green	Y/B	Yellow/Black
Gy	Gray	Y/G	Yellow/Green
Lg	Light green	Y/R	Yellow/Red
Sb	Sky blue	Br/W	Brown White